Model : KTE-1000BA STANDARD REFRIGERATION EXPERIMENTAL EQUIPMENT GUIDEBOOK Ver.1.1.0







Chapter 1. Description of a Standard Refrigeration system

1-1. System Description of Standard Refrigeration	3
1-2. Component of mechanical standard refrigeration system	4
1-3. Control panel device component of standard refrigeration system	9
1-4. Description of DA100 features	16

Chapter 2. How to way operating equipment and DA100 & Coolpack

2-1.	System operation	18
2-2.	DA100 Installation and Setting	19
2-3.	Drawing a P-h diagram using Coolpack	41

Chapter 3. Experiment and Analysis of standard refrigeration system

3-1.	Basic experiment of a standard refrigeration system	50
3-2.	Measurement of cooling performance according to condensation temperature change	57
3-3.	Measurement of cooling performance according to evaporation temperature change	64

Chapter 4. Practice of automatic control using sequence and PLC training

4-1.	Practice to configuration self-holding circuit for priority STOP of using sequence	
	control	74
4-2.	Practice to configuration self-holding circuit for priority STOP of PLC programming	77
4-3.	Practice to configuration of temperature switch using sequence control	84
4-4.	Practice to configuration of temperature switch using PLC programming	89
4-5.	Practice to configuration of low pressure switch(LPS) using sequence control	97
4-6.	Practice to configuration of low pressure switch(LPS) using PLC programming	104
4-7.	Practice to configuration of high pressure switch using sequence control	109
4-8.	Practice to configuration of HPS on pressure switch using sequence control	114
4-9.	Practice to configurate direct circuit for low temperature (T_S/W) and low pressure	
	(LPS) control with a refrigeration system	118
4-10.	Practice to configuration of pump down control circuit using sequence control	124
4-11.	Practice to configuration of pump down control circuit using PLC programming	129
4-12.	Configuration hot gas defrosting circuit and operation	134
4-13.	Configuration electric heat defrosting circuit and operation	137

Chapter 5. Notice and Guarantee

1.	Mechanical trouble and measures	139
2.	Caution Notice on operation	139
\bigcirc	Warrantee and A/S application sheet	140

Chapter 1. Description of a Standard Refrigeration system



1-1. System Description of Standard Refrigeration

1. CONTROL PANEL : Comosition with N.F.B, Toggle Switch, Am.Vm meter, Buzzer, Lamps(Red, Green, Orange), High.Low Pressure Switch, Magnetic Contactor, Relays, Thermal Switch, Push Buttons, Power Input, these devices make the refrigeration system run by several electric circuit.


2. MECHANICAL REFRIGERATION : Composition with Compressor, Condenser(with fan motor), Receiver, Filter-dryer, Sight glass, Solenoid Valve, Manual expansion Valve, Evaporator(with fan motor), High.Low pressure gauge, these devices run as set up circuit in Control panel.

3. SOFTWARE P/G: KTE-DA100(Software) supply tools with that temperature, pressure, enthalpy, amount of the exchanged heat in each position can be measured in real time, and then saved by Microsoft excel, so that the saved data can be show and analysis by graph.

4. HARDWARE PCB : Composition with KTE-DA100(Hardware), ,S.M.P.S, 9 of K-Type Thermo couple and 4 of Pressure sensor, these devices let all of data from system as like temperature, pressure, enthalpy, amount exchanged heat in each position and COP acquisited to software at PC.



1-2. Component of mechanical standard refrigeration system



(1) Compressor



- * Specification
 - 1/2HP
 - Range : Medium, High temperature
 - Motor Type : CSR
 - Refrigerant : R-134a
 - Single phase 220V, 50/60 Hz
 - Controller

The motor compressor absorbs heat from an object in the evaporator of the standard refrigeration test equipment, increases the pressure by compressing the vaporized gas refrigerant at low-temperature and low-pressure and reduces the distance between molecules. Then, it increases the temperature and thus makes the gas easily in the condenser at the room temperature. That is, it sends the heat from the evaporation of refrigerant at the low heat source(evaporator) to the superheat source(condenser) at the high temperature and pressure.



(2) Condenser



* Specification Size : 400(W) \times 280(H) \times 210(D)mm Motor : AC220V 5-60Hz 4P 9W Capacity : 3/4 HP

The condenser emits and condenses the refrigerant gas heat at the high temperature and pressure from the compressor to the air at the room temperature. It condenses and liquidizes the heat of gaseous refrigerant through the heat exchange between the gaseous refrigerant at the high temperature and pressure from the compressor and the surrounding air or cooling water. The condenser emits the hot blow as the external device. The refrigerant gas from the compressor is liquidized to the refrigerant liquid.

The condenses the refrigerant gas from the compressor at the high temperature and pressure to the liquid refrigerant at the high temperature and pressure through the heat exchange between the refrigerant gas and water or air at the room temperature. The reason to change the refrigerant gas to the liquid state is to use the latent heat during the change of state. The highest volume of heat can be taken from the evaporator when using the latent heat, that is, when the liquid state is changed to the gaseous state. If the condenser is installed in the place with too higher external temperature or lower ventilation because of foreign substances, the condensing temperature and pressure become increased so that the evaporator will not work properly. Thus, the refrigeration effect can be improved when the condenser is installed near the compressor and on the place that is well ventilated without direct sunlight. The condenser requires the special attention for more effective heat exchange with the external air through the regular fan cleaning. The condenser receives, condenses and liquidizes the refrigerant gas from the compressor. Higher refrigeration effect(that is, if the heat exchange between the coolant and refrigerant gas is well processes) of the condenser reduces the temperature and condensing pressure inside the condenser. The condenser works at the constant condensing temperature as the volume of refrigerant gas from the compressor keeps the balance with the cooling operation of condenser.

(3) Nipple



The charging nipple is the requisite to use the manifold gauge for the airtight and vacuum tests and refrigerant filling and transferring of the standard refrigeration test equipment. It is attached to the low and high pressure ducts on the mechanical compressor output and input sides. Before soldering the charging nipple to the high and low pressure ducts on the compressor output and input sides, the internal rubber(for keeping the airtight state) ring is removed and set again after refrigeration.



(4) Liquid Receiver



Refrigerant that flows from condenser stays at a receiver before it goes expansion valve. The amount of staying refrigerant at a receiver must be constant for control refrigerant amount emitting into an evaporator. And also it need for recharging (pump down operation) when its repair.

(5) Filter Drier



Any moisture or impurities that exist in the refrigerants have a variety of negative impacts on the refrigerators. Then, the filter drier removes moisture or impurities. It is installed between the expansion valve and the receiver.

(6) Solenoid Valve



The electronic valve for main duct controls the refrigerant flow as it is opened or closed depending on the power input. It is connected to the temperature switch in series during the pump-down operation. In this case, the pump-down operation is processed by the opening or closing of the electronic valve for the main duct according to the closing or opening of temperature switch contact.

(7) Expansion Valve



Manual Expansion Valve

The manual expansion valve insulates and expands the high temperature and pressure liquid refrigerant to the low temperature and pressure liquid refrigerant for easy expansion in the expander. The condensed and liquidized refrigerant is rapidly discharged from the narrow side to the wide side(crossing action) and starts the evaporation because the pressure is removed. Moreover, the volume of refrigerant is properly adjusted for the absorption of sufficient heat in the evaporator.



(8) Evaporator



The evaporator performs the heat exchange activity to directly achieve the refrigeration goals as the low temperature and pressure liquid refrigerant from the expansion valve absorbs the latent heat of evaporation. The evaporator absorbs the latent heat of evaporation from the low temperature and pressure liquid refrigerant from the expansion valve to directly refrigerate an object(copper duct aluminumpinair).

(9) High Pressure Gauge



This device is for measurement of refrigerant pressure behind of compressor, liquid type high pressure gauge. Range is $-1 \sim 35$ kgf/cm2.

(10) Low Pressure Gauge



This device is for measurement of refrigerant pressure front of compressor, liquid type low pressure gauge. Range is -1 \sim 20kgf/cm2.

(11) Heater



This device is for electric defrost heating, installed at evaporator, input power is AC220V.



(12) Sight Glass



A sight grass that is for indication of refrigerant charging level and status with direct and simple way is available to HFC, HCFC, CFC family with no matter within -50° C $\sim +80^{\circ}$ C. Overcharging of refrigerant makes lubricating oil happening bubble, compression liquid, so that it makes an accident sometimes. For protecting this, through an installed sight grass refrigerant should be charged suitable.

(13) Data Performance Automatic Measurement Equipment




This device roles to be acquisitive temperature and pressure data at all of position in a refrigeration system. Temperature point : 16 ea (BA : 9 ea) Pressure point : 16 ea (BA : 4 ea) Input Power : DC 5V Ref.) See its software program for each detail position.

(14) Pressure Sensor



This sensor measures high pressure, low pressure, condensing pressure, and evaporating pressure in a refrigeration system. Input power : DC 5V Output : 0.5~4.5V





1-3. Control panel device component of standard refrigeration system

(1) Main Power (N.F.B)



Main Power



Toggle Switch

The over current breaker(N.F.B) protects the compressor motor, fan motor of condenser or evaporator or wires of the refrigeration training equipment from the over current due to overloads or short circuit. The circuits are automatically cut out so that the equipment stops operation. It is not required to replace like a fuse if any cutout is occurred. The power can be immediately and easily reentered just using a handle.

After connection between equipment and power line, for flowing of current a NFB is used, and then a AC LAMP will be on. And also if a Toggle switch is on, a DATA LOG device is on.



(2) DC Volt, Ampere Meter



Volt meter (Analog type)


This device installed in equipment measures voltage and current by DC.

(3) Buzzer




The buzzer and alarm lamp display the abnormal status when a thermal relay and safety devices(H.P.S) are working. That is, the alarm lamp is more effective than the buzzer in the noisy places and the buzzer is more effective than the alarm lamp for the color blind operators in the quiet working places. Using both the buzzer and alarm lamp will be ideal.

(4) Lamp



The power lamp(P.L) is on when the power is connected and the operating lamp (G.L) is on during the operation. the stop lamp(R.L) is on when the operation stops and the emergency lamp or alarm lamp(Y.L) displays the abnormal status during the operation such as operation of thermal relay. The reserve lamp(Y.L) circuit can be configured to be turned on when the automatic control devices such as low temperature switch, temperature control switch and condensation and pressure control switch are operating.





The Dual Pressure Switch(DPS) is the set of HPB and LPS. If the high pressure is over a certain level or the low pressure is below a certain level, it stops the motor for compressor. The excessively low differential pressure of LPS induces frequent setout of compressor and this is called Hunting.

On the contrary, the excessively high differential pressure of LPS extends the down time too much. So the temperature in the refrigeration room is increased. This is called Off Set.

A. L.P.S Low pressure control

In Fig. 1-22, the right part of dotted line shows setting value (RANGE) of low pressure, the other part difference (DIFF).

- A Set your desirable low pressure value by screw pin using screw driver.
- B Set your desirable difference value by screw pin using screw driver.
- © Connect between 'H' or 'L' and 'com' as your desirable control.
- D LPS-L Line OUT

(When the desire value is lower than your setting value, connect 'com' and 'L')

€ LPS-H Line OUT

(When the desire value is upper than your setting value, connect 'com' and 'H'.)

B. H.P.S High pressure control

A Set your desirable high pressure value by screw pin using screw driver.


B LPS-L Line OUT

(When the desire value is lower than your setting value, connect 'com' and 'L') © LPS-H Line OUT



(When the desire value is upper than your setting value, connect 'com' and 'H', RESET : return.)

(6) Magnetic Contactor



Magnetic contactor (MC) controls compressor motor, condenser motor, solenoid valve and evaporator motor through sequence circuit.

- 1) DC Power red is +, black -.
- 2 When DC power is on, A contact sticks to each other, so current can flow, and B contact separated, so current cut.




Relay controls compressor motor, condenser motor, solenoid valve and evaporator motor through sequence circuit.

- 1) DC Power red is +, black -.
- 2) When DC power is on, each contactor 1-3, 8-6 are connected each other
 - (Flow current), at same time separated contactor 1-4, 8-5 each other(Close current).





(8) Temperature Switch



The digital temperature meter(Temp Meter) for measuring temperature measures on a defined areas for the performance test when the refrigeration training equipment is running. Then, it draws the pressure-enthalpy diagram with the measured temperature for the performance test of refrigeration training equipment. At this moment, the digital temperature meter is required to measure the temperature on each area. The performance test of refrigerator will be separately described.

- ① Setting temperature value by push set button.
- ② Choose temperature value by push up or down button.
- ③ Setting deviation value.
- ④ Connect contactor 'com' and '+ '.
- ⑤ Connect contactor 'H' or 'L' and '+'.


(9) On/Off Switch



This device is for start, stop, or ON/OFF. ① PB1 is for Running (A contact) ② PB2 is for Stop (B contact)




(10) Toggle Switch



This device is for start, stop, or ON/OFF. ① Connect 'C' and '+' power, operate by selection of 'a' or 'b'

(11) Temperature Display



Comp in : Display temp. at compressor inlet Comp out : Display temp. at compressor outlet Exp. v. in : Display temp. at expansion valve inlet Exp. v. out : Display temp. at expansion valve outlet

Condenser out : Display temp. at condenser outlet Eva. v. out : Display temp. at evaporator outlet

(12) DC Power input



- COMP : Compressor Motor CFM : Condenser Fan Motor EFM : Evaporator Fan Motor SV : Solenoid Valve
- HD : Hot Gas Defrost
- ED : Electric Defrost



(13) DC Power Output



Plug for electric circuit among each devices (Red plug +, Black -)


(14) Condenser, Evaporator Fan Motor Speed Control



This device controls motor speed of condenser fan motor or evaporator fan motor, right turning speed up, and left turning down. Through motor speed control, efficiency of condensing or evaporating can be controled.



1-4. Description of DA100 features



Performance monitoring software using main equipment

- ① Refrigeration
- KTE-1000BA
- 00BA : Standard Refrigeration Trainer
- KTE-1000TP : Temperature, Pressure & Defrost Control Refrigeration Trainer
- KTE-2000EP : Evaporation Pressure Parallel Control Trainer (E.P.R Control)
 - KTE-2000EV : Refrigerant Parallel Expansion Refrigeration Trainer
- KTE-3000HD-H : 4-Way Reverse Valve Control Heat Pump Heating Trainer
- KTE-3000HD-C : 4-Way Reverse Valve Control Heat Pump Cooling Trainer
- KTE-5000LT : Binary Refrigeration Trainer
- KTE-6000BR : Brine Refrigeration Trainer (Ice Maker)
- KTE-9000AU : Car Air-conditioner (A/C) Trainer
- KTE-1000AHU : Air-Handling Unit Trainer
- KTE-2000AHU : Air-Handling Unit Trainer

② Solar Heat Geothermal


- KTE-7000SR : Solar Radiation Energy Experiment Equipment
- KTE-7000SB : Solar Heating Hot Water Boiler Experiment Equipment
- KTE-7000PVT : PVT Performance Measuring Equipment
- KTE-7000GH-H : Geothermal Heat Pump (Heating) Experiment Equipment
- KTE-7000GH-C : Geothermal Heat Pump (Cooling) Experiment Equipment

3 Solar / Wind Generation

- KTE-HB520 : Hybrid Power Conversion Experiment Equipment
- KTE-7000SG : Solar Power Generation Experiment Equipment
- KTE-7000WG : Wind Power Generation Experiment Equipment
- KTE-7000SH : Solar Beam Hydrogen Cell Experiement Equipment



■ Structure of DA100



Main Screen of Standard Refrigeration System


- (1) Diagram of Standard Refrigeration System
 - : Compressor \rightarrow Condenser \rightarrow Filter Dryer \rightarrow Sight Glass \rightarrow Solenoid Valve \rightarrow Manual Expansion Valve \rightarrow Evaporator \rightarrow Compressor
- (2) Measuring of Temperature, Pressure, Enthalpy
- (3) Drawing P-h diagram on real time
- (4) Refrigerating effect (qe), Compressor work (Aw), Condensation effect (qc), Coefficient of Performance (COP)
- (5) Feature of save data
- (6) Feature of capture for P-h diagram
- Features of DA100 program
- ① Monitoring the measured data of temperature and pressure in real time
- 2 Monitoring the measured data of enthalpy on a refrigeration system in real time
- ③ Monitoring factors like as refrigeration effect, compressor work, evaporating, latent heat, amount of falssh gas at expansion valve outlet, dry ratio at expansion valve outlet, coefficient of performance in the abstract with temperature and pressure data which are measured in real time
- ④ Being saved data all temperature, pressure and enthalpy as excel micro office
- (5) Experiment for drawing a P-h diagram as measured temperature and pressure



Chapter 2. How to way operating equipment and DA100 & Cautions

2-1. System operation

- ① Connect the cable
 - Red cable with (+) pole
 - Black cable with (-) pole



③ Check the liquid refrigerant through sight glass when operating system



2 When operating the system, checking pressure gauge (Low and High pressure)



- Type of Refrigerant : R-134a

- Compressor Capacity : 1/2 HP
- Amount of Charge gas : 600 g

④ If the condensation does not work properly, adjust the fan motor speed to control the load.



- CFM : Condenser Fan Motor
- EFM : Evaporator Fan Motor
- ⑤ Check the temperature display on control panel



* How to way charging gas, please note KTE-ER09 on International Textbook.



2-2. DA100 Installation and Setting

2-2-1. KTE-DA100 Installation and Operating

🛃 KTENG Setup	
📸 setup	



Select Installation	Folder		5
The installer will install KTENG §	Setup to the following folder.		
To install in this folder, click "Ne	ext". To install to a different folder	, enter it below or	click "Browse".
Californi			
Folder:			
Eolder: C:₩Program Files (×86))₩KTENG Setup₩		Browse
)₩KTENG Setup₩		B <u>r</u> owse <u>D</u> isk Cost
C:₩Program Files (×86))₩KTENG Setup₩ self, or for anyone who uses this o	computer:	
C:₩Program Files (×86)		computer:	

KTENG Setup	
Confirm Installation	5
The installer is ready to install KTENG Setup on yo	our computer.
Click "Next" to start the installation.	
	ancel (gack Next)
	and chore works

- ① You can see a installation files that in CD or USB for installation then double click 'KTENG Setup' file to start installation. If the progrma cannot be installed using 'KTENG Setup', try to 'setup file.
- ② If you can see a 'Setup Wizard' screen, click the 'Next>'.

- ③ You can change a installation route. If you want to change a installation route. click the 'Browse..' and find a new route then click the 'Next>'
- ④ If require to confirm installation intention. Please click the 'Next>'



2-2-2. Install USB to Serial

- (1) Communication method is using computer and RS232 protocol for communication.
- (2) If you got a desktop which is connected with Serial Port back. you don't have to install USB To Serial.
- (3) If you got a desktop which doesn't have note book or Serial Port, you need to install progress for collecting data using USB Port.
- ① Installation to USB_RS232 Driver on PC or Labtop
- ② After reading

"2012591631_USB_to_Serial_Converter", Following screen is indicated. And double click



③ You can check this screen as below. Double click this icon "CDM20600", and after installation to driver on PC or Labtop

2018-12-26 오후	파일 폴더	
2018-12-26 오후	파일 콜터	
2010-01-06 오후	서식 있는 텍스트	102KB
2010-01-06 오후	응용 프로그램	2,291KB
2010-01-06 오후	응용 프로그램	428KB
2010-01-06 오후	H 파일	23KB
2010-01-06 오후	보안 카탈로그	12KB
2010-01-06 오후	설치 정보	5KB
2010-01-06 오후	보안 카탈로그	11KB
2010-01-06 오후	설치 정보	6KB
2010-01-06 오후	응용 프로그램	411KB
	2018-12-26 오후 2010-01-06 오후 2010-01-06 오후 2010-01-06 오후 2010-01-06 오후 2010-01-06 오후 2010-01-06 오후 2010-01-06 오후	2018-12-26 오후 파일 풀더 2018-12-26 오후 파일 풀더 2010-01-06 오후 서식 있는 텍스트 2010-01-06 오후 응용 프로그램 2010-01-06 오후 응용 프로그램 2010-01-06 오후 보안 카탈로그 2010-01-06 오후 보안 카탈로그 2010-01-06 오후 보안 카탈로그 2010-01-06 오후 보안 카탈로그 2010-01-06 오후 보안 카탈로그

⑤ Click the "Hardware tap".

Click "Start"//Option//into Control Panel. Double click "System" in Control Panel.

④ Method to set Communication Port



<u>!</u> 컴위 장치 관리 종종	뛰던 이를 [하드웨어] 고급 시스템 복원 자동 업데이트 원격 자
	장치 관리자(D)
сеюнн Су	드라이버 서명으로 설치된 드라이버가 Windows와 호환되는지 화인할 수 있으며 드라이버 검색을 위해 Windows Update에 연결하는 방법을 설정할 수 있습니다.
	드라이버 서명(S) Windows Update(W)
하드웨어	프로필 하드웨어 프로필은 사용자가 다른 하드웨어 구성을 설정하고 저장할 수 있는 방법을 제공합니다.
	하드웨어 프로필(P)



 $\textcircled{\sc blue}$ Click "Device Administrator. Next you can check the USB port number.



⑦ When you click like picture, emerge USB SERIAL PORT. After mouse right click "USB SERIAL PORT" and click "Attribute."

<u>*</u>	포트 설정 드라이	비비 자세히
3	USB Serial Por	t(COM11)
	장치 유형:	포트 (COM 및 LPT)
	제조업체:	FTDI
	위치:	USB High Speed Serial Converter
장치	상태	
	장치가 올바르게 작	
이 전 행하	장치에 문제가 발생 십시오.	하면 [문제 해결]을 클릭하여 문제 해결을 실
		문제 해결(王)
치사	용(<u>D</u>):	
장치	1 사용(사용 가능)	

⑧ Click "Port option"

비트/초(B): 9600	×
데이터 비트(D): 8	~
패리티(<u>P</u>): 없음	~
정지 비트(<u>S</u>): 1	~
흐름 제어(E): 없음	~

③ Click "High rank"

			가 발요함)(년)				
	에 문제가 있 도를 빠르게		'을 낮추고 강을 높이십시오.				(Ø&
수신 버迅(B):	対部(1)		1	-0	鉴容 (14)	(14)	기본값([
응십 HB(I):	낮음 (1)	ŝ		ą	筆音(16)	(16)	




⁽¹⁾ After setting appropriately to port for user equipment. Click OK.

(1) Locate the folder where DA100 is installed on the Local C:Drive. Find : "KTENG Setup"

📕 KSign	2014-04-01
🍌 KTENG	2018-11-29
길 KTENG Setup	2018-04-02
KTEng0917	2014-03-20

- D Right Click "Property"
- ⁽³⁾ You should enter the "Security" and Check all allow "Administrations"




⁽⁴⁾ You should check again all allow "SYSTEM"

실반 공유 보안 이전 버?	3 사용자 지정	8	
개체 이름: C:\Program Fil	les (x86)₩K.TI	ENG Setu	p
그룹 또는 사용자 이름(G):			
& CREATOR OWNER			
SVSTEM			
& Administrators (YJ-RNDWA	dministrators)		-
사용 권한을 변경하려면 [편집]을 클릭하십시오.		편집	(E)
SYSTEM의 사용 권한(P)	\$	18	거부
모든 권한	1		*
수정	1		13
읽기 및 실행	1		E
풍더 내용 보기	V	1	
읽기	- V		
특정 권한 및 고급 설정을 보려면 하십시오.	[고급]을 물덕	-	2/10
하십시오.		11	3(V)
역세스 체대와 사용 권한에 대한 경	2 1 2 2 2 2 2 2 2 2 2 2 2 2 2		



2-2-3. Composition of DA100

(1) Start program by using icon in wallpaper or routing folder then the main page of program come up.




Model.	Equipment	Model.	Equipment
KTE-1000BA	Standard Refrigeration Eqxperiment Equipment	KTE-7000SR	Solar Radiation Energy Experiment Equipment
KTE-1000TP	Temperature, Pressure & Defrost Control Refrigeration Equipment	KTE-7000SB	Solar Heating Hot Water Boiler Experiment Equipment
KTE-2000EP	Evaporation Pressure Parallel Control Experiment Equipment	KTE- 7000PVT	PVT Performance Measuring Equipment
KTE-2000EV	Refrigerant Parallel Expansion Valve Experiment Equipment	КТЕ- 7000GH-Н	Geothermal Heat Pump Experiment Equipment
КТЕ- 3000HD-Н	4-Way Reverse Valve Control Heat Pump Experiment Equipment (Heating Mode)	КТЕ- 7000GH-С	Geothermal Heat Pump Experiment Equipment
КТЕ- 3000HD-С	4-Way Reverse Valve Control Heat Pump Experiment Equipment (Cooling Mode)	KTE-HB520	Hybrid Power Conversion Experiment Equipment
KTE-5000LT	Binary Refrigeration Experiment Equipment	KTE-7000SG	Solar Power Conversion Experiment Equipment
KTE-6000BR	Brine Refrigeration Experiment Equipment	KTE-7000WG	Wind Power Conversion Experiment Equipment
KTE-9000AU	Car Air-Conditioner Experiment Equipment	KTE-7000SH	Solar-Hydrogen Fuel Cell Experiment Equipment
KTE- 1000AHU	Air-Conditioning Unit Automatic Control Equipment		
КТЕ- 2000АНU	Air Handling Unit Lab-View Programming Equipment		



(2) Main Menu Composition




(3) View




(Refrigeration 11, Solar Heat/Geothermal 5, Solar/Wind Generation 4)

(4) Setting



(5) Control





(6) Setting

Menu	Explain
Offset Setting	Setting initial pressure, temperature
Serial Setting	Communicating port setting
Save Interval Setting	Setting data acquisition time interval
PH Offset Setting	Setting range of axis at p-h chart
Refrigerant Setting	Select refrigerants


(7) Control

Menu	Explain
PLC emulator	Using PLC control
Digital output	Control a Hardware
Temp, pressure	Control a temperature, pressure



2-2-4. Application of data acquisition equipment (KTE-DA100)


(1) Selection of Model



When program started.
 'View' screen is activated.


② Select a model what you want.

(Click the KTE-1000BA)



③ Main user interface of KTE-1000BA is activated.






(2) Composition of main user interface

(1)Schematic diagram of system show temp, press, in realtime.

② P-h chart

(3) Data table of temp, press, and enthalpy.

(4) Calculation value of COP. cooling capacity, heat capacity in HX.



○○ · 철유터 · 로컬 디스크 (C:) · Program Files (x86) · KTENG Setup · SaveData

이름

🛲 다른 이름으로 저장 👘 👘

구성 ▼ 새 몰더

☆ 즐겨찾기 🚺 다운로드

📕 바탕 화면

🔛 최근 위치


詞 라이브러리 💽 문서 📑 비디오

사진
 음악

📳 컴퓨터

🔺 롤더 숨기기

🏭 로컬 디스크 (C:) 🕞 로컬 디스크 (D:) 파일 이름(N):



수정한 날짜

유형

일치하는 항목이 없습니다.

① Click a toggle switch to run program to save data.

② Write a title and save a file by excel.

* The reason of writing title first is that can save data even though unavoidable situation happened.



취소

23


Q

8**=** • 0

▼ 4g | SaveData 검색


37

(4) Find a graph



 If you want to see a temp, and press,

graphically, please click a icon in red box below.




Temperature Realtime Graph




Pressure Realtime Graph

② You can always see the graph for location and figure through checking temperature, pressure




③ Seeing the graph for individual temperature and pressure is that double click display of monitor then indicate the graph window as below.




④ You can always check the temperature.




(5) Function for capture



 The bottom of the right side, click image cpature flow chart and image capture PH then it is saved to JPG files.







- ② Monitor when choosing
- Diagram (Flow Chart) capture
- PH diagram capture

Diagram capture (Flow Chart)

PH diagram capture









② When you click (R) for before size, the window is activated for moving


1	View	🥢 Setting	Con 😳
8	이전 크기	로(B)	
	可蚕瓜的		
	크기 조정	1	
-	최소화(N)	
	최대화(X)		10.4
×	달기(Q)	Ctrl+F4	- c
	다음①	Ctrl+F6	-

③ Click that button, the window is bigger.









(5) When click the minimum, indicate bottom of the left side.


5	View	🧳 Setting	Contr
8	이전 크기	星(18)	-
	0(否(M)		
_	371 23	1215	8
4	최소화(1)	D	
	최대화(X	1	ap 4 Se
×	달기(<u>C</u>)	Ctrl+F4	E C
	다음①	Ctrl+F6	

6 When click whole monitor, it is returned.






() view	(7)	View
---------	-----	------



① Click the view in tools.




② When you click the view and click Model name then it goes to main screen and it indicates program screen which is connected with real equipments.



(8) Setting

(i) Serial setting




Port . COM1 Cancel O K

③ COM No is changed depend on port location. choose COM NO and Click OK.

* Checking port No is on Page use to serial installation




(ii) Offset setting




① Click Setting in Tools



② When you click Offset setting, below screen is indicated.



KTE-DA100 - [KTE-2000EP] 🔨 🖹 View 📝 Setting 😡 Control Offset setting Temp Serial setting Graph Save interval setting PH offset setting Refrigerant setting 1



③ Temp Offset Zero is that can control temperature

Offset

🕑 : You can control using direction key

0.0 : It is counter indication for temperature figure. Click the application then click the Close for applying the figure.



Offset setting				0
Temp Offset Zero Volta	ge Offset Zero Temp's Pa	rameter 📜 Voltage's Parame		-
Voli	Vol2	Vol3	¥014	ĥ
			8888 🝣	
Offset 0.0 counter 0.0	Offset 0.0	Offset 0.0 counter 0.0	Offset 0.0 counter	
Vol5	Vol6	Vol7	Vol8	
			8000 😂	
Offset 0.0 counter 0.0	Offset 0.0 counter	Offset 0.0 counter	Offset 0.0	
Vol9	Vol10	Vol11	Vol12	
Offset 0.0 counter	Offset 0.0 counter	Offset 0.0 counter	Offset 0.0 counter	
Vol13	Vol14	Vol15	Vol16	J
				Ŧ
Start saving		R	eset Appliance Close	D

④ Voltage Offset Zero is a part of can control voltage.

You can control using direction key.

Offset 0.0 : It is indication for voltage figure Click the application then click the Close for applying the figure.

(5) Temp's Parameter must enter a value of Y=70X-150 on all of the items is a place to enter a formula that converts the output signal of the thermometer with temperature. click the "Application" and click "Close" for Application.

⑥ Voltage's Parameter has a function which can input the figure for changing input figure, You can set as choosing Pressure, Voltage.
Click "Application" and click "Close" for

Application.

Temp1	Temp2	Temp3	Temp4
Y = 70 文 X + -150 文	Y = 70 ♀ X + -150 ♀	Y = 70 ♀ X + -150 ♀	Y = 70 ♀ X + -150 ♀
Temp5	Temp6	Temp7	Temp8
Y = 70 + X + -150 +	Y = 70 ♀ X + -150 ♀	Y = 70 • X + -150 •	Y = 70 \$ X + -150 \$
Temp9	Temp10	Temp11	Temp12
Y = 70 🔹 X + -150 🗘	Y = 70 • X + -150 •	Y = 70 • X + -150 •	Y = 70 • X + -150 •
Temp13	Temp14	Temp15	Temp16
Y = 70 🗘 X + -150 🗘	Y = 70 • X + -150 •	Y = 70 • X + -150 •	Y = 70 \$ X + -150 \$


Vol1	Vol2	Vol3	Vol4
Y = 1 🔷 X + 0 🗘	Y = 1 🔹 X + 0 🛊	Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘
Press O Voltage	Press O Voltage	Press O Voltage	Press O Voltage
Vol5	Vol6	Vol7	Vol8
Y = 1 🗢 X + 0 🗘	Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘
Press O Voltage	Press O Voltage	Press O Voltage	Press O Voltage
Vol9	Vol10	Vol11	Vol12
$Y = 1 \diamondsuit X + 0 \diamondsuit$	Y = 1 🗘 X + 0 🗘	Y = 1 🗢 X + 0 🗢	Y = 1 🗘 X + 0 🗘
Press O Voltage	Press O Voltage	Press O Voltage	Press
Vol13	Vol14	Vol15	Vol16
Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘
Press	Press Voltage	Press	Press O Voltage




Vol1	Vol2	Vol3	Vol4
Y = 1 🛟 X + 0 🗘	Y = 1 🛊 X + 0 🛊	Y = 1 🗘 X + 0 🗘	Y = 1 🗘 X + 0 🗘
Press O Voltage	🖲 Press 🔘 Voltage	Press O Voltage	Press O Voltage
Vol5	Vol6	Vol7	Vol8
Y = 1 🗘 X + 0 🗘	Y = 1 🛊 X + 0 🛊	Y = 1 🗘 X + 0 🛟	Y = 1 🗘 X + 0 🛟
Press O Voltage	Press O Voltage	Press O Voltage	Press O Voltage
Vol9	Vol10	Vol11	Vol12
Y = 1 🔹 X + 0 🜲	Y = 1 🔹 X + 0 🜲	Y = 1 🗢 X + 0 🗢	Y = 1 🗘 X + 0 🛟
Press O Voltage	Press O Voltage	Press O Voltage	Press O Voltage
Vol13	Vol14	Vol15	Vol16
Y = 1 🗘 X + 0 🗘	Y = 1 🔹 X + 0 🛊	Y = 1 🗢 X + 0 🗘	Y = 1 🛊 X + 0 🛊
Press O Voltage	Press O Voltage	Press	Press O Voltage


⑦ Start saving set figure and Click "Close" on the left screen.

(iii) Save interval setting






① Click Save interval setting




② Save interval setting is a function for setting a data storage time interval. The time interval as an Excel file can be stored in line. (However, the number of seconds Sec) because when set to one minute is ste to 60 sec.




(iv) PH offset setting



② Click PH offset setting






PH offset setting	
Press $Y = 1 \stackrel{\bullet}{\updownarrow} X + 0 \stackrel{\bullet}{\diamondsuit}$	Enthalpy Y = 1 🗘 X + 0 🗘
	ОК

③ On the main screen the PH offset setting.

The axis values of the Enthalpy adjustment function.





(v) Refrigerant setting




1) Click Setting







🔪 🗎 View 🛛	🎸 Setting 🛛 🥥 Control
	Offset setting
Temp	Serial setting
Graph	Save interval setting
Low Pres	PH offset setting
Low F	 Refrigerant setting



③ Refrigerant setting is a function for selecting the refrigerant 1-stage refrigeration cycle. Refrigeration 2-stage refrigeration cycle is selected for the selection of the Refrigerant - 2 Refrigerant and can be applied to the program. Click "OK"





구성 ▼ 새 콜더					1911 -	• 🔟	6
😙 즐겨찾기 🕺	아름	수정한 날짜	유형	크기			
L 다운로드	图 R11	2013-04-19 오후	Microsoft Excel	1,100KB			
🔜 바탕 화면	R12	2013-05-01 오후	Microsoft Excel	878KB			
💹 최근 위치	R13	2013-04-19 오후	Microsoft Excel	869K8			
	R14	2013-04-19 오후	Microsoft Excel	1,030KB			
글 라이브러리	R21	2013-05-02 오후	Microsoft Excel	372K8			
문서	B-22최종냉매값	2013-04-19 오후	Microsoft Excel	833KB			
표비디오 =	(편) R23최종냉매값	2013-04-19 오후	Microsoft Excel	764KB			
🖬 사진	R50	2013-04-19 오후	Microsoft Excel	1,231KB			
👌 음악	🗐 R113	2013-05-02 오전	Microsoft Excel	1,077KB			
	R114	2013-04-19 오후	Microsoft Excel	962KB			
📕 컴퓨터	🕲 R123	2013-05-02 오전	Microsoft Excel	540KB			
📇 로컬 디스크 (C:)	R134a	2013-04-19 오루	Microsoft Excel	821KB			
급 로컬 디스크 (D:)	R152a	2013-05-02 오후	Microsoft Excel	459K8			
BD-ROM 드라이	R170	2013-04-19 오후	Microsoft Excel	877KB			
	🖾 R290	2013-04-19 오후	Microsoft Excel	961KB			
🖬 네트워크 🍼	图1 R401A	2013-05-07 오프	Microsoft Excel	928KB			
파일	이름(N): InenFileDialogi			- 5	dsx files (*.xlsx)		-,

(4) Select the type of refrigerant and click "Open" to apply to the program.

(9) Control


(i) Digital output











3 Digital output is the second comp by number and to the switch ON/OFF when you work with equipment to operating the stand relay and the operation or without through the lamp Function to determine.



(ii) Temp, Pressure

. 8	0A100 - [KTE-10008] View / Setting								8 3
	ph Graph Tread Terms 1 Terms 1 Terms 2 Condensare Terms 2	Re Liquid Riceiver	Manual Expansion Value Totan I ar Dise	999A d adviguestion Trainer	50				
0	Compresso ENG	Temp I. Press J.	4	Law Presses Yes	0 -, 150		300 nthalpy [kJ/kg]	350 4	ióo
(KT		(000.0 Dar	Pressure(bar)	Nat Preservice	0 -, 150	200 250		350 4	
(KT	ENG	(1000 tr) (Pressure(bar)	Nat Prove Ve	0-1 150	200 250 B		100001 (
KT NO 1	ENG	(1000 tr) (Pressure(bar)	Nat Prove Ve	0-1 150 Qe	200 250 Ei h1 - h6 = h1 - h5		100001 (
(K7 No 1 2	Compressor In	(1000 tr) (Pressure(bar)	Nat Prove Ve	0- 150 Qe AW	200 250 Ei h1 - h6 = h1 - h5 h2 - h1		100001 (
К7 No 1 2 3	ENG Compressor In Compressor Out	(1000 tr) (Pressure(bar)	Nat Prove Ve	0-1 150 Qe AW Qc	200 250 Ei h1 - h6 = h1 - h5 h2 - h1 Qe + AW = h2 - h5		100001 (
К7 No 1 2 3	ENG Compressor In Compressor In Compressor Out Condenser In	(1000 tr) (Pressure(bar)	Nat Prove Ve	0-1 150 Qe AW Qc Qr	200 250 Er h1 - h6 = h1 - h5 h2 - h1 Qe + AW = h2 - h5 hg - hf		RU	N
KT NO 1 2 3 4 5	Item Compressor In Compressor Out Condenser In Condenser Out	(1000 tr) (Pressure(bar)	Nat Prove Ve	0, 150 Qe Qc Qr Qf	200 250 Er h1 - h6 = h1 - h5 h2 - h1 Qe + AW = h2 - h5 hg - hf h6- hf		Ru Inge (JN J Captur chart
KT NO 1 2 3 4 5 6	Item Compressor In Compressor In Compressor Out Condenser In Condenser Dut Espansion V/V In	(1000 tr) (Pressure(bar)	Nat Prove Ve	0	200 250 E h1-h6 = h1-h5 h2 = h1 Qe + AW = h2 - h5 hg - hf h6-hf Qf/Qr		RU	Captur chart
KT NO 1 2 3 4	Item ENG Compressor In Compressor Out Compressor Out Condenser In Condenser Out Espansion V/V In Evaporator In	(1000 tr) (Pressure(bar)	Nat Prove Ve	0 150 0e Aw 0c 0r 0f x y	200 250 250 250 250 250 250 250 250 250		Ru Inge (JN J Captur chart


Run / Stop	Temp	Deviation	Pressure	Deviation	Temp	Press
Part1	0.0°C	5.0°C	0,0 Bar	1,000.0 Bar		
Part2	0.0°C	5.0°C	0,0 Bar	3.0 Bar		
Part3	0.0°C	5.0°C	0.0 Bar	3.0 Bar		
Part4	0.0°C	5.0°C	0.0 Bar	3.0 Bar		100
Position	Temp sensor	Pressure	Digital out	put		
Position1	1 -		1,2			
Position1 Position2	1 ▼ 2	1	1,2 Not	,	Using t	the con
(0)			(2000) 		Using 1	the con ance

- Temp sensor : Choose location of temperature sensor.
- Pressure : Choose location of Pressure sensor.
- Digital output : Choose location of output.

① Click Control

2 Temp, Pressure has a function which is interlock with temperature and pressure.

When click "Temp, Pressure", indicate the window as below



③ Temp(set temperature) deviation.


Pressure(set pressure) deviation is indicated deviation and it can be saving the figure you want and it can choose both Temp and Pressure. Temp sensor : Selection for pressure sensor location Digital output : Selection output port what you want to control After setting, Click "Appliance" and "Close".




2-3. Drawing a P-h diagram using Coolpack

1. Refrigerant Utilities

① Click "Refrigeration Utilities"




② Click a P-h diagram






③ Click a Refrigerent (Example_The refrigerant used varies depending on the equipment)
 - KTE-3000HD : R-134a



- ④ Click a "R-134a"
 - Click "Cycle"






(5) Cycle input

Select cycle type: One stage Two stage, open inter	rcooler C		, closed intercooler , open intercooler, load at in	termedia	ite pressure	Edit cycle
Cycle name:				N	Draw cycle	Update
<u>Values:</u> Evaporating temperature: Sugerheat: Dp evaporator: Dp suction line: Dp discharge line: Isentropic efficiency [0-1]:	0.00	했 ▼ K ▼ Bar ▼ Bar ▼ Q loss	Condensing temperature: Su <u>b</u> cooling: Dp condenser: Dp liquid line:	0.00	図 ・ K ・ Bar ・ Bar ・	Calculated: Qe [kJ/kg]: 10000.000 Qc [kJ/kg]: 10000.00 COP: 2.34 W [kJ/kg] 10000.00 W high [kW] 10000.00
Draw cycle Show info	o Co	py cycle	Paste cycle Canc	el	Help	(m high)/(m low 0.00000000 m low [kg/s]: 0.00000000 m high [kg/s]: 0.00000000

- 2. How to applicate the program
 - (1) Choose your respecting refrigeration system cycle on 'Select cycle type'
 - ① One stage cycle
 - ② Two stage cycle
 - (2) Evaporating Temperature (°C) or evaporating pressure (bar) on running.
 - (3) Condensing Temperature (°C) or condensing pressure (bar) on running.
 - (4) Superheat : Superheating temperature (°K) from outlet of evaporator to inlet of compressor.
 - (5) Sub Cooling : Sub cooling temperature (°K) from outlet of condenser (or saturating line on p-h chart) to in front of expansion valve.
 - (6) DP Evaporator : Temperature (or pressure) Difference between outlet of expansion valve and outlet of evaporator.
 - (7) DP Condenser : Temperature (or pressure) Difference between inlet of condenser and inlet of expansion valve.
 - (8) DP Suction line : Temperature (or pressure) Difference between outlet of evaporator and inlet of compressor.
 - (9) DP Liquid line : Temperature (or pressure) Difference at inlet of expansion valve after isolation expansion process.
 - (10) DP Discharge line : Temperature (or pressure) Difference between outlet of compressor and inlet of condenser.



(11) P-h Diagram





3. Refrigeration cycle and P-h diagram

(1) Refrigeration cycle




Fig. 4-1. KTE-1000BA Diagram

(2) Analysis Data

1) Data Table

Table 4-1. Data Table

Data point	Table1	Table2	Table3	Table4	Table5	Remark
Evaporation Temperature						
Superheat						
DP Evaporator						
DP Suction line						
DP Discharge						
Condensing Temperature						
Sub Cooling						
DP Condenser						
DP Liquid Line						



2) Calculate heat amount and performance note Table

Oper Station	Compression Ratio	-	erating fect		nsation acity	СОР	Work by Compressor
1		KJ/kg	Kcal/kg	KJ/kg	Kcal/kg		Kcal/kg
Table1							
Table2							
Table3							
Table4							
Table5							

Table 4-2. Calculating of heat amount and Note Table of performance

4. Example drawing a P-h diagram

(1) Data measuring_Variable evaporation Temp

Data point	Table1	Table2	Table3	Remark
Evaporation Temp	-15 °C	-10 °C	-5℃	
Condensing Temp	40 °C	40 °C	40 °C	
Isentropic efficiency	1	1	1	
Qe [kJ/kg]	132.157	135.161	138.124	
Qc [kJ/kg]	169.933	168.734	167.675	
COP	3.5	4.03	4.67	
W [kJ/kg]	37.775	33.573	29.551	
Pressure Ratio	6.193	5.063	4.176	

Table 4-3. Data measurement


(2) Data measuring_Variable Condensing Temp

Table 4-4. Data measurement

Data point	Table1	Table2	Table3	Remark
Evaporation Temp	-15 °C	-15 °C	-15 °C	
Condensing Temp	40 °C	30 °C	20 °C	
Isentropic efficiency	1	1	1	
Qe [kJ/kg]	132.157	146.855	161.083	
Qc [kJ/kg]	169.933	178.744	186.662	
COP	3.5	4.61	6.30	
W [kJ/kg]	37.775	31.889	25.578	
Pressure Ratio	6.193	4.692	3.483	




(3) Drawing solution P-h diagram



1) Drawing solution about No.1 on Table 4-3.

Fig. 4-3. Solution about No.1 on Table 4-3



2) Drawing solution about No.1 on Table 4-4.

3) Note a performance test result

Oper Station	Compression Ratio	EĤ	erating fect		nsation acity	СОР	Work by Compressor
	compression runne	KJ/kg	Kcal/kg	KJ/kg	Kcal/kg		Kcal/kg
Table1							
Table2							
Table3							
Table4							
Table5							

Table 4-5. Note a performance test result

- 4) Drawing each P-h diagram as each refrigerant
- (1) Condition
 - 1) Evaporating temperature : -15°C
 - 2) Condensing temperature : 30°C
 - 3) Temperature at inlet of compressor: -15°C(Dry gas)
 - 4) Temperature at inlet of expansion valve: -25°C(sub-cooling temp. 5°C)
- (2) Formula
 - 1) Refrigeration ability (Qe) = $h_{\rm a}$ $h_{\rm e}$
 - 2) Compressor work (W) = $h_b h_a$
 - 3) Condensing load (Qc) = $h_b h_e$ = Qe + W
 - 4) Coefficient of performance (COP) = Qe/W
 - 5) Compression Ratio (Pr) = P_2/P_1
- (3) Comparing each Coefficient of performance as each refrigerant



Refrigerant	Qe	Qc	СОР	W	Pr
R-11 (CCI3F, Trichlorofluoromethane)	159.749	190.663	5.17	30.914	6.191
R-113 (CCI2FCCIF2, Trichlorotrifluoroethane)	129.450	154.908	5.08	25.457	8.005
R-114 (CCIF2CCIF2, Dichlorotetrafluoroethane)	103.463	124.941	4.82	21.478	5.372
R-12 (CCI2F2, Dichlorodifluoromethane)	121.284	146.024	4.90	24.740	4.079
R-123 (CHCI2CF3, Dichlorotrifluoroethane)	147.310	176.082	5.12	28.772	6.885
R-1270 (CH3CH=CH2, Propene (propylene))	300.752	363.752	4.77	63.001	3.588
R-134a (CH2FCF3,1,1,1,2-tetrafluoroethane)	154.023	185.913	4.83	31.889	4.692
R-152a (CH3CHF2,1,1-difluoroethane)	254.328	304.795	5.04	50.467	4.530
R-170 (CH3CH3, Ethane)	198.987	258.244	3.36	59.257	2.883
R-21 (CHCI2F, Dichlorofluoromethane)	198.987	258.244	3.36	59.257	2.883
R-22 (CHCIF2, Chlorodifluoromethane)	169.243	204.180	4.84	34.937	4.031
R-290 (CH3CH2CH3, Propane)	293.156	354.359	4.79	61.203	3.717
R-401A, R22/152a/124 (53/13/34), R401A	173.946	209.582	4.88	35.635	4.597
R-401B, R22/152a/124 (61/11/28), R401B	174.475	210.351	4.86	35.876	4.527
R-401C, R22/152a/124 (33/15/52), R401C	167.261	201.184	4.93	33.923	4.742
R-402A, R125/290/22 (60/2/38), R402A	121.226	147.912	4.54	26.686	3.881
R-402B, R125/290/22 (38/2/60), R402B	139.268	169.072	4.67	29.804	3.930
R-404A, R125/143a/134a (44/52/4), R404A	122.321	149.700	4.47	27.379	3.895
R-406A, R22/142b/600a (55/41/4), R406A	197.305	234.413	5.32	37.108	4.632
R-407A, R32/125/134a (20/40/40), R407A	160.990	195.456	4.67	34.466	4.390
R-407B, R-32/125/134a (10/70/20)	126.736	154.856	4.51	28.119	4.198
R-407C, R-32/125/134a (23/25/52)	175.779	212.765	4.75	36.987	4.468
R-408A, R22/143a/125 (47/46/7)	155.205	195.115	3.89	39.909	3.957
R-409A, R22/124/142b (60/25/15)	169.267	210.536	4.10	41.269	4.601
R-410A, R32/125 (50/50)	176.684	214.942	4.62	38.259	3.862
R-410B, R32/125 (45/55)	168.311	204.736	4.62	36.426	3.908
R-500, R12/152a (73.8/26.2)	147.010	177.105	4.88	30.095	4.105
R-502, R-22/115 (48.8/51.2)	110.620	134.616	4.61	23.996	3.784
R-507, R-125/143a (50/50)	125.721	152.951	4.62	27.229	3.852
R-600 (CH3CH2CH2CH3, Butane)	301.166	361.834	4.96	60.667	4.977
R-600a (CH(CH3)3, 2-methyl propane (isobutane))	277.180	333.691	4.90	56.511	4.560
R-717 (NH3, Ammonia)	1127.528	1358.669	4.88	231.141	4.940
R-718 (H20, Water)	2369.155	2959.889	4.01	590.734	25.687
R-744 (C02, Carbon dioxide)	161.693	210.777	3.29	49.084	3.143
RC318 (C4F8, Octafluorocyclobutane)	43.696	60.481	2.60	16.785	5.386

Table 4-6. Comparing each Coefficient of performance as each refrigerant



Chapter 3. Experiment and Analysis of standard refrigeration System

Experiment Name	3-1. Basic experiment of standard refrigeration system Class (hr 24				
 (1) Study the basic operating principles of standard refrigeration system (2) Study and analyze of refrigeration performance using operating 					
experiment the standard refrigeration system (3) Using the measured data, draw a P-h diagram with the Coo program and analyze the refrigeration performance					
Equi	pment and Software	Tools	Spec of Toos	Q'nty	
. Standard Re	frigeration Experiment	• Driver	→ #2×6×175mm	1	
Equipment (KTE-1000BA)		• Nipper	• 150mm	1	
. Refrigeration	performance data	• Wire Stripper	· 0.5∼6mm [*]	1	
acquisition of	device (KTE-DA100)	• Hook Meter	· 300A 600V	1/Group	
. Coolpack					

(1) Order of experiment

- 1) Check the condition
 - ① Temperature of Outdoor Air
 - ② Capacity of compressor
 - ③ Amount of charging refrigerant
 - ④ Check condensation and evaporation temperature, pressure gauge before system operating




Fig 3-1. Diagram Standard Refrigeration System



(2) Experiment

① Experiment 1, Outdoor air : 23 °C

Operation State 1	Comp In.	Comp Out.	Condenser In	Condenser Out	Exp.V.In	Eva. In	Eva. Out	Chamber
Temp	6.4 °C	65.4 °C	58.7 °C	34.2 °C	23.8 °C	-6 ℃	6.4 °C	3.5 °C
Press	1.8 bar	8.7 bar	-	8.6 bar	-	1.9 bar	_	-
Enthalpy	407.1 kJ/kg	447.8 kJ/kg	-	233.1 kJ/kg	-	233.1 kJ/kg	-	-

Table 3-1. Case 1_Measurement Data Temperature, Pressure, Enthalpy

Table 3-2. Calculated Value

Data point	Calculation method	Value
Evaporation Temp	Measurement point at Eva. In	-6 °C
Condensing Temp	Measurement point at Condenser. Out	34.2 ℃
Qe [kJ/kg]	Refrigeration ability : Qe = $h_a - h_e$	174 kJ/kg
Qc [kJ/kg]	$Qc = h_b - h_e = Q_e + A_W$	214.7 kJ/kg
СОР	Coefficient of Performance (COP) = $\frac{Q_e}{A_W}$	4.2781
W [kJ/kg]	Compressor Work (W) = $h_b - h_a$	40.7 kJ/kg
Pressure Ratio	Compression Ratio (Pr) = P2 / P1	4.8

Table 3-3. How to applicate the coolpack program

Data point	Explanation	Value
Evaporating temperature	Temperature at inlet evaporator on running [${}^{\mathbb{C}}$]	- 6 °C
Condensing temperature	Temperature at outlet condenser on running [°C]	34.2 °C
Superheat	From outlet of evaporator to inlet of compressor [K] Or Temperature inlet of compressor [°C]	6.4 °C
Subcooling	Subcooling temperature [K] from outlet of condenser (or saturated line on P-h diagram) to inlet of expansion valve	10.4 K
Dp evaporator	Temperature (or pressure) difference between outlet of expansion valve and outlet of evaporator	0.1 bar
Dp Condenser	Temperature (or pressure) difference between inlet of condenser and inlet of expansion valve	0.1 bar
Dp Suction line	Temperature (or pressure) difference between oulet of evaporator and inlet of compressor	_



(2) Experiment

① Experiment 2, Outdoor air : 23 °C

Operation State 1	Comp In.	Comp Out.	Condenser In	Condenser Out	Exp.V.In	Eva. In	Eva. Out	Chamber
Temp	6.4 °C	66.2 °C	60 °C	34.8 °C	24.8 °C	-6.5 ℃	6.2 °C	2.7 °C
Press	1.8 bar	8.7 bar	-	8.7 bar	_	1.9 bar	-	-
Enthalpy	407.1 kJ/kg	448.9 kJ/kg	_	234.6 kJ/kg	_	234.6 kJ/kg	_	_

Table 3-4. Case2_Measurement Data Temperature, Pressure, Enthalpy

Table 3-5. Calculated Value

Data point	Calculation method	Value
Evaporation Temp	Measurement point at Eva. In	-6.5 ℃
Condensing Temp	Measurement point at Condenser. Out	34.8 ℃
Qe [kJ/kg]	Refrigeration ability : Qe = $h_a - h_e$	172.6 kJ/kg
Qc [kJ/kg]	$Qc = h_b - h_e = Q_e + A_W$	214.3 kJ/kg
СОР	Coefficient of Performance (COP) = $\frac{Q_e}{A_W}$	4.1364
W [kJ/kg]	Compressor Work (W) = $h_b - h_a$	41.7 kJ/kg
Pressure Ratio	Compression Ratio (Pr) = P2 / P1	4.8

Table 3-6. How to applicate the coolpack program

Data point	Explanation	Value		
Evaporating temperature	Temperature at inlet evaporator on running $[{}^{\mathbb{C}}]$	- 6.5 °C		
Condensing temperature	Temperature at outlet condenser on running [°C]			
Superheat	From outlet of evaporator to inlet of compressor [K] Or Temperature inlet of compressor [°C]	6.4 °C		
Subcooling	Subcooling temperature [K] from outlet of condenser (or saturated line on P-h diagram) to inlet of expansion valve	10.0 K		
Dp evaporator	Temperature (or pressure) difference between outlet of expansion valve and outlet of evaporator	0.1 bar		
Dp Condenser	Temperature (or pressure) difference between inlet of condenser and inlet of expansion valve	0.0 bar		
Dp Suction line	Temperature (or pressure) difference between oulet of evaporator and inlet of compressor	_		



(2) Experiment

① Experiment 3, Outdoor air : 23.3 °C

Operation State 1	Comp In.	Comp Out.	Condenser In	Condenser Out	Exp.V.In	Eva. In	Eva. Out	Chamber
Temp	5.7 °C	78.4 ℃	71.9 ℃	38.1 °C	30.4 ℃	-8.5 ℃	2.5 °C	2 °C
Press	1.8 bar	9.5 bar	_	9.5 bar	-	1.9 bar	_	_
Enthalpy	406.3 kJ/kg	460.6 kJ/kg	_	243.2 kJ/kg	_	243.2 kJ/kg	_	_

Table 3-7. Case3_Measurement Data Temperature, Pressure, Enthalpy

Table 3-8. Calculated Value

Data point	Calculation method	Value
Evaporation Temp	Measurement point at Eva. In	-8.5 ℃
Condensing Temp	Measurement point at Condenser. Out	38.1 ℃
Qe [kJ/kg]	Refrigeration ability : Qe = $h_a - h_e$	163.1 kJ/kg
Qc [kJ/kg]	$Qc = h_b - h_e = Q_e + A_W$	217.5 kJ/kg
СОР	Coefficient of Performance (COP) = $\frac{Q_e}{A_W}$	3.0013
W [kJ/kg]	Compressor Work (W) = $h_b - h_a$	54.4 kJ/kg
Pressure Ratio	Compression Ratio (Pr) = P2 / P1	5.3

Table 3-9. How to applicate the coolpack program

Data point	Explanation	Value
Evaporating temperature	Temperature at inlet evaporator on running $[{}^{\rm C}]$	- 8.5 °C
Condensing temperature	Temperature at outlet condenser on running [°C]	38.1 °C
Superheat	From outlet of evaporator to inlet of compressor [K] Or Temperature inlet of compressor [°C]	5.7 °C
Subcooling	Subcooling temperature [K] from outlet of condenser (or saturated line on P-h diagram) to inlet of expansion valve	7.7 K
Dp evaporator	Temperature (or pressure) difference between outlet of expansion valve and outlet of evaporator	0.0 bar
Dp Condenser	Temperature (or pressure) difference between inlet of condenser and inlet of expansion valve	0.0 bar
Dp Suction line	Temperature (or pressure) difference between oulet of evaporator and inlet of compressor	_



- (2) Experiment
- ① Experiment 4, Outdoor air : 23.3 °C

Operation State 1	Comp In.	Comp Out.	Condenser In	Condenser Out	Exp.V.In	Eva. In	Eva. Out	Chamber
Temp	5.8 °C	78.8 ℃	71.9 °C	37.7 °C	30.0 °C	-9.5 ℃	3.4 °C	2.3 °C
Press	1.7 bar	9.4 bar	_	9.3 bar	_	1.8 bar	_	-
Enthalpy	406.3 kJ/kg	460.6 kJ/kg	_	241.7 kJ/kg	-	241.7 kJ/kg	_	-

Table 3-10. Case4_Measurement Data Temperature, Pressure, Enthalpy

Table 3-11. Calculated Value

Data point	Calculation method	Value
Evaporation Temp	Measurement point at Eva. In	-9.5 ℃
Condensing Temp	Measurement point at Condenser. Out	37.7 ℃
Qe [kJ/kg]	Refrigeration ability : Qe = $h_a - h_e$	164.6 kJ/kg
Qc [kJ/kg]	$Qc = h_b - h_e = Q_e + A_W$	189.1 kJ/kg
СОР	Coefficient of Performance (COP) = $\frac{Q_e}{A_W}$	3.028
W [kJ/kg]	Compressor Work (W) = $h_b - h_a$	54.4 kJ/kg
Pressure Ratio	Compression Ratio (Pr) = P2 / P1	5.5

Table 3-12. How to applicate the coolpack program

Data point	Explanation	Value
Evaporating temperature	Evaporating temperature Temperature at inlet evaporator on running [°C]	
Condensing temperature Temperature at outlet condenser on running [°C]		37.7 ℃
Superheat	From outlet of evaporator to inlet of compressor [K] Or Temperature inlet of compressor [°C]	5.8 °C
Subcooling	Subcooling temperature [K] from outlet of condenser (or saturated line on P-h diagram) to inlet of expansion valve	7.7 K
Dp evaporator	Temperature (or pressure) difference between outlet of expansion valve and outlet of evaporator	0.1 bar
Dp Condenser Temperature (or pressure) difference between inlet of condense and inlet of expansion valve		0.1 bar
Dp Suction line	Temperature (or pressure) difference between oulet of evaporator and inlet of compressor	_




- (3) Data analysis
- ① Compare with result of experiment

Table 5 15. Compare with data the result of experiment							
Experiment	Evaporation Temperature	Condensation Temperature	Superheat	Subcooling	COP		
Experiment 1	-6 ℃	34.2 °C	6.4 °C	10.4 K	4.2781		
Experiment 2	-6.5 ℃	34.8 ℃	6.4 °C	10.0 K	4.1364		
Experiment 3	-8.5 ℃	38.1 °C	5.7 °C	7.7 K	3.0013		
Experiment 4	-9.5 ℃	37.7 ℃	5.8 °C	7.7 K	3.028		

Table 3-13.	Compare	with	data	the	result	of	experiment	
-------------	---------	------	------	-----	--------	----	------------	--


② Drawing P-h diagram using coolpack : Experiment 4



Experiment 3-1. Basic experiment of standard refrigeration system								
name	0 1. 1	511 5950			24			
1. Prac 2. Usir	ng the D	Standard Refrigeration Experim [KTE-1000BA] basic operation of standard re 0A100, measured the temperation	efrigera ure and	ation s d pres	system	data	n, ar	nd
	P values							
	-	and analyze the data using	g save	excel	file a	and c	Irawir	ng
tne	P-h dia							
		Appraisal	Aliot	Point		Ren	nark	
		Check ambient temperature and refrigerant charge	10					
	Work	Check expansion valve opening amount	10					
Relationship between	(Point 70)	Evaporator chamber damper operation	10					
technical description	technical Organize measurement data and drawing 20							
rating items and task	rating items Task Drawing of P-h graph according to 10							
	(Point 10)	condensation load Review and Result	20					
	Time (Point 20)	 Demerit mark Point () in minute after finish 	every	()	Work	Task	Time	Total



Experiment	3-2. Measurement of coolin		according to	Class time (hr)				
Name	(high temperature control) 24							
The object of experiment	 (1) The condenser load control (1) The condenser load control operation measurement. (2) Condenser ability experimental Excel file. (3) Experimental measurement exchange capacity, and performent 	mental save the r ent temperature,	neasurement d pressure, enth	ata as an alpy, heat				
Equ	ipment and Software	Tools	Spec of Too	os Q'nty				
Equipment (frigeration Experiment KTE-1000BA) performance data acquisition -DA100)	 Driver Nipper Wire Stripper Hook Meter 	 #2×6×175mm 150mm 0.5~6mm 300A 600V 	n 1 1 1/Grou p				
- Indepen	-	rature						
《Experimen	tal Study on Cooling Load by C	Controlling Evapora	ator Damper》					
1) Coolin								
_	b back door							
- Open to	o front door(Damper)							
② Refrig	geration							
- Close te	o back door							
- Open to	o front door(Damper)							
3 Coolin	ng Load Control							
- Back de	oor (open or close)							
- Front d	loor (0 ~ 100%) adjustable							
	TENG 57	Korea Technoloby Engine	ering Co.,Ltd.					



(2) Diagram (Temp, Press and Heat Exchange amount)


Comp. In : Compressor inlet Comp. Out : Compressor outlet Condenser In : Condenser inlet Condenser Out :Condenser outlet Expan. V. In : Expansion valve inlet Expan. V. Out / Evaporator In : Expansion out(Evaporator in) : Expansion valve outlet Evaporator : Evaporator outlet

- qe : Refrigeration effect
- AW : Compressor work
- qc : Condensing heat amount
- qr : Evaporating latent heat
- qf : Flash gas

qe : Refrigeration effect AW : Compressor work qc : Condensing heat amount gr : Evaporating latent heat qf : Flash gas x : Dry ratio y : wet COP : Coefficient of Performance

x : Dry ratio y : Humidity COP : Coefficient of Performance r : Pressure Ratio





	(1)	-15	40	132.157	169.933	3.5	37.775	
	(2)	-15	30	146.855	178.744	4.61	31.889	
	(3)	-15	20	161.083	186.662	6.3	25.578	
								-
T 1.				•	•••••••••	+ la		

The increase of the condensation pressure increases the compression ratio to increase the temperature of the discharge gas, thereby reducing the refrigeration effect and simultaneously increasing the compression days, thereby reducing the coefficient of performance.




(4) Measurement data

1) Measurement Temperature

	Comp.In	Comp. Out	Expan.V.	Heat E	Exp.V.N.1	Heat E	Heat E 2	Outside
1sec	-1	55	49	35	-8	-13	3	19
2sec	0	55	49	35	-8	-13	3	19
3sec	0	55	49	35	-8	-13	3	19
4sec	0	54	48	35	-7	-13	3	19
5sec	0	54	48	35	-7	-13	3	19
6sec	0	54	48	35	-7	-13	3	19
7sec	1	54	48	35	-7	-13	4	19
8sec	1	54	48	35	-7	-13	4	19
9sec	1	54	48	35	-7	-13	4	19
10sec	1	53	47	35	-6	-13	4	19
•	•	•	•	•	•	•	•	
·	•	•	•	•	•	•	•	•

① Temperature Compressor In & Out


	Comp. In	Comp. Out
1sec	-1	55
2sec	0	55
3sec	0	55
4sec	0	54
5sec	0	54
•	•	
•	•	•



[5] Temperature of compressor In & Out

② Temperature of Condenser In & Out


	Cond. In	Cond. Out
1sec	49	35
2sec	49	35
3sec	49	35
4sec	48	35
5sec	48	35
		•
•		•





③ Temperature of expansion valve In & Out


	Exp. In	Exp. Out
1sec	18	-8
2sec	18	-8
3sec	18	-8
4sec	17	-7
5sec	17	-7
•	•	•
•	•	•



[7] Temperature of expansion valve In & Out

④ Temperature of evaporator In & Out

	Eva.In	Eva. Out
1sec	-8	-13
2sec	-8	-13
3sec	-8	-13
4sec	-7	-13
5sec	-7	-13
•		
•		•




[8] Temperature of evaporator In & Out

2) Measurement Pressure Data

	Low	High	Condensing	Evaporating
1sec	2.3	12.3	12.3	2.2
2sec	2.3	12.3	12.3	2.2
3sec	2.3	12.2	12.3	2.2
4sec	2.3	12.2	12.3	2.2
5sec	2.3	12.2	12.3	2.2
6sec	2.3	12.2	12.3	2.2
7sec	2.3	12.2	12.3	2.2
8sec	2.3	12.2	12.3	2.2
9sec	2.3	12.2	12.3	2.3
10sec	2.3	12.2	12.3	2.3
		•		•
		•		•





Experiment	3-2. Measurement of cooling performance according to	Class time (hr)
name	condensation temperature change	0.4
name	(high temperature control)	24

- · Experimental method
- 1. Operation circuit as manual operation, cooling and heating automatic temperature control
- 2. Condensation load : Hyper condensed load, Normal operation, Insufficient condensation load
- 3. The evaporation load is kept constant.

· Check Point


- 1. Prepare measurement equipment, tools and materials and check communication and refrigerant charge state.
- 2. Using the measuring equipment, it meets the given measurement method and conditions and constructs the condenser load control operation.
- 3. The condensation capacity measurement data according to the load fluctuation of the condenser is stored in an Excel file, and reliable data of a predetermined section is selectively stored.
- 4. The selected reliability data is further divided into temperature, pressure, enthalpy, heat exchange capacity, and coefficient of performance.
- 5. Construct a graph using stored temperature, pressure, enthalpy, heat exchange capacity, and coefficient of performance data.
- 6. Analyze the cause and content of the graph drawn in the Excel file and organize it.
- 7. The condensation capacity analysis results of condenser load variation are reviewed and the conclusions are summarized.

			Rem	ark				
		Check ambient temperature and refrigerant charge	10					
	Work (Point	Check expansion valve opening amount	10					
between 70	70)							
technical description		Organize measurement data and drawing P-h graph	20					
rating items and task	Task (Point	Drawing of P-h graph according to condensation load	10					
	10)	Review and Result	20					
	Time (Point 20)	 Demerit mark Point () in minute after finish 	-	()	Work	Task	Time	Total



				ass time				
Experimental name	3-3. Measurement of coolin		_	(hr)				
numo	evaporation temperature cha			24				
	(1) The evaporator load con	trol operation ci	rcuit can be con	figured				
The	for operation measurement.	a amarimant d	ata ia aavad aa a	Erral				
experiment of	(2) The evaporator performar file.	ice experiment da	ata is saveu as ai	I EXCEI				
ODJECT	object ^{111e.} (3) Measurement temperature, pressure, enthalpy, heat ex							
	and performance coefficient da	-		-				
Eq	uipment and Software	Tools	Spec of Tools	Qyn't				
. Standard	Refrigeration Experiment							
Equipment (K7	ГЕ-1000ВА)	• Driver	、#2×6×175mm	1				
. Refrigeration	performance data acquisition	• Nipper	• 150mm	1				
device (KTE-	DA100)	• Wire Stripper	· 0.5∼6mm [*]	1				
. Coolpack		• Hook Meter	• 300A 600V	1/Grou				
				р				
- Manipul	dent variable : Ambient Tempera ation variable : Speed control fa tal Study on Cooling Load by Co	an of evaporator	ator Damper»					
① Cool	ing							
- Ope	n to back door							
- Ope	n to front door(damper)							
② Refri	geration							
- Clos	se to back door							
- Ope	- Open to front door(damper)							
③ Cool	ing load control							
- Bacl	– Back door (open or close)							
 Front door (0 ~ 100%) adjustable 								





2. Diagram (Measurement temperature and pressure, Heat Exchange rate)


Comp. In : Compressor inlet Comp. Out : Compressor outlet Condenser In : Condenser inlet Condenser Out :Condenser outlet Expan. V. In : Expansion valve inlet Expan. V. Out / Evaporator In : Expansion out(Evaporator in) : Expansion valve outlet Evaporator : Evaporator outlet

- qe : Refrigeration effect
- AW : Compressor work
- qc : Condensing heat amount
- qr : Evaporating latent heat
- qf : Flash gas

qe : Refrigeration effect AW : Compressor work qc : Condensing heat amount qr : Evaporating latent heat qf : Flash gas x : Dry ratio y∶wet COP : Coefficient of Performance

x : Dry ratio y : Humidity COP : Coefficient of Performance r : Pressure Ratio







5. Measurement Data

(1) Measurement temperature data

Evaporation load : wet compression

	Comp. In	Comp. Out	Cond. In	Cond. Out	Exp. In	Exp. Out	Eva. Out	Eva.	Out
1sec	6	39	35	32	8	0	-8	12	22
2sec	6	38	35	32	8	0	-8	11	22
3sec	6	38	35	32	8	0	-9	11	21
4sec	6	38	35	32	8	0	-9	10	21
5sec	6	38	35	32	8	0	-10	10	20
6sec	6	38	35	32	8	0	-10	9	20

Evaporation load : dry compression

	Comp. In	Comp. Out	Cond. In	Cond. Out	Exp. In	Exp. Out	Eva. Out	Eva.	Out
1sec	1	69	62	34	24	-12	-16	-11	17
2sec	1	69	62	34	23	-12	-16	-11	17
3sec	1	69	62	34	23	-12	-16	-10	17
4sec	1	69	62	34	23	-12	-16	-10	17
5sec	1	68	62	34	22	-11	-16	-10	17
6sec	2	68	62	34	22	-11	-15	-9	17


Evaporation load : Over heat compression

	Comp. In	Comp. Out	Cond. In	Cond. Out	Exp. In	Exp. Out	Eva. Out	Eva.	Out
1sec	1	69	62	34	24	-12	-16	-11	17
2sec	1	69	62	34	23	-12	-16	-11	17
3sec	1	69	62	34	23	-12	-16	-10	17
4sec	1	69	62	34	23	-12	-16	-10	17
5sec	1	68	62	34	22	-11	-16	-10	17
6sec	2	68	62	34	22	-11	-15	-9	17
7sec	2	68	62	34	22	-11	-15	-9	17
8sec	2	68	61	34	21	-10	-15	-9	17
9sec	2	68	61	34	21	-10	-14	-9	17
10sec	2	67	61	34	21	-10	-14	-8	17
11sec	3	67	61	34	20	-10	-14	-8	17
12sec	3	67	61	34	20	-9	-14	-8	17
13sec	3	67	61	34	20	-9	-13	-7	17




1) Temperature of Compressor In & Out

	Comp. In	Comp. Out
1sec	6	39
2sec	6	38
3sec	6	38
4sec	6	38
5sec	6	38
6sec	6	38
•		•
•	•	•
	•	•




2) Temperature of Condenser In & Out

	Cond. In	Cond. Out
1sec	35	32
2sec	35	32
3sec	35	32
4sec	35	32
5sec	35	32
6sec	35	32
•	•	•
•	•	•
	•	



[6] Temperature of Condenser In & Out






[7] Temperature of Expansion Valve In & Out

4) Temperature of Evaporator In & Out

	Eva. In	Eva. Out
1sec	0	-8
2sec	0	-8
3sec	0	-9
4sec	0	-9
5sec	0	-10
6sec	0	-10
•		•
•	· ·	•





(2) Measurement Pressure Data

	Low	High	Condensing	Evaporating
1sec	2.7	11.4	11.5	2.6
2sec	2.7	11.4	11.5	2.6
3sec	2.7	11.4	11.4	2.6
4sec	2.7	11.4	11.4	2.6
5sec	2.7	11.4	11.4	2.6
6sec	2.7	11.4	11.4	2.6

Evaporation load : Wet compression


Evaporation load : Dry compression


	Low	High	Condensing	Evaporating
1sec	2.2	12.1	12.1	2.2
2sec	2.3	12.1	12.1	2.2
3sec	2.3	12.1	12.1	2.3
4sec	2.4	12.1	12.1	2.3
5sec	2.5	12.1	12.1	2.4
6sec	2.5	12.1	12.1	2.4

Evaporation load : Over heat compression

	Low	High	Condensing	Evaporating
1sec	2.2	12.1	12.1	2.2
2sec	2.3	12.1	12.1	2.2
3sec	2.3	12.1	12.1	2.3
4sec	2.4	12.1	12.1	2.3
5sec	2.5	12.1	12.1	2.4
6sec	2.5	12.1	12.1	2.4
7sec	2.5	12.1	12.1	2.5
8sec	2.6	12.1	12.1	2.5
9sec	2.6	12.1	12.1	2.6
10sec	2.7	12	12.1	2.6
11sec	2.8	12	12.1	2.7
12sec	2.8	12	12.1	2.7
13sec	2.8	12	12.1	2.8
14sec	2.9	12	12.1	2.8
15sec	2.9	12	12.1	2.8
16sec	2.9	12	12.1	2.9
17sec	3	12	12.1	2.9
18sec	3	12	12.1	3








[9] Pressure of Compressor In & Out

2) Pressure of Condenser In & Out

1) Pressure of Compressor In & Out

	Cond. In	Cond. Out
1sec	11.4	11.5
2sec	11.4	11.5
3sec	11.4	11.4
4sec	11.4	11.4
5sec	11.4	11.4
6sec	11.4	11.4
	•	•
•		•
•	•	•




[10] Pressure of Condenser In & Out



	Eva. In	Eva. Out
1sec	11.5	2.6
2sec	11.5	2.6
3sec	11.4	2.6
4sec	11.4	2.6
5sec	11.4	2.6
6sec	11.4	2.6
•	•	•
•	•	•
		•

3) Pressure of Evaporator In & Out



[11] Pressure of Evaporator In & Out



Experiment
name

3-3. Measurement of cooling performance according to evaporation temperature change(low temperature control) Class time (hr) 24

· Experimental method

- 1. Operation circuit as manual operation, cooling and heating automatic temperature control
- 2. Evaporation load : Wet compression, Dry compression, Over heat compression
- 3. The condensation load is kept constant.

· Check Point

- 1. Prepare measurement equipment, tools and materials and check communication and refrigerant charge state.
- 2. Experiments are carried out by constructing the evaporator load control operation circuit satisfying the given measurement method and conditions using the measure equipment.
- 3. The evaporation performance measurement data is stored as an excel file according to the variation of the evaporator load, and reliable data of a predetermined section is selected and stored.
- 4. The final stored data is classified by temperature, pressure, enthalpy, heat exchange capacity, and performance coefficient.
- 5. Draw a graph using stored temperature, pressure, enthalpy, heat exchange capacity, and coefficient of performance data.
- 6. Analyze the cause and content of the graph drawn in the Excel file and orgnaize it.
- 7. The results of the analysis of the evaporative capacity measurement data according to the evaporator load variation are concluded.

		Appraisal	Aliot	Point		Ren	nark	
		Check ambient temperature and refrigerant charge	20					
Polationship	Work (Point	Check expansion valve opening amount	20					
	70)	Condenser fan motor speed maintenance	10					
technical description		Data analysis and draw p-h graph	20					
rating items	Task	Draw the P-h graph due to evaporation load	5					
and task	(Point 10)	Organize material tools	5					
	Time (Point 20)	• Demerit mark Point () in ev minute after finish	ery ()	Work	Task	Time	Total




Chapter 4. Practice of automatic control using sequence and PLC training

Experiment	4-1. Practice to configuration self-h	olding circuit for		Class tir	me(hr)
name	priority STOP of using sequence	-		8	
The object of experiment	 To understand self-holding circu standard refrigeration system as To describe self-holding circuit standard refrigerator. 	the circuit.		_	
	Experiment equipments	Tool & material	Spec o	of tools	Q'nty
. Standard (KTE-1000	refrigeration Experiment Equipment BA)	. Driver . Nipper . Wire Stripper . Hook meter	. #2 [.] 175mm . 150m . 0.5~6 . 300A	m mm²	1 1 1/Grou p
	Control Circu	it			
1. Control ci	L1(+) L2(-) N.F.B MC1_a0g Og THR	О РВ1 80 Ry1 6 0 РВ1 0 Ry1_а 0 30 Ry1_а 0 30 MC1 (_a		
N.F. MC :	B : No fuse circuit breaker S Magnet contactor coil Pl	FM : Condenser Fan M V : Solenoid V/V B : Push button OMP : Compressor m			




2. Manual Operating Circuit(Self-Holding Circuit) Design and Configuration in Refrigerator



The manual operating circuits are configured, tested and experimented using the banana jacks in accordance with the refrigeration cycle drawings and operating circuits. The circuit designs and configuration principles are described below. Turn the Start button on, and the MC coil(MC Electric Coil) is excited. So the relay circuit "a", the main contact, is closed and the Motor Compressor and Condenser Fan Motor run. Then, the normal operation is started. Press the Stop button to turn the circuit off, and the MC coil(MC Electric Coil) is demagnetized. Then, the main contact is opened and so the Motor Compressor, Condenser Fan Motor and Evaporator Fan stop.

For the manual operation of refrigerator, the self-holding circuit is configured and operated using the relay circuit "a" of the magnetic switch(MC Electric Coil). Press the Start button, and the refrigerator runs. Press the Stop button, and the refrigerator stops. This is the basic application control circuit in the refrigeration devices.




When the N.F.B is opened, the break light(RL) of the relay circuit 'b' is on as the magnetic switch (MC Electric Coil) is demagnetized. Press the Start button, and the magnetic switch (MC Electric Coil) is excited. Then, the relay contact "a", the main contact, is closed and so the Motor Compressor, Condenser Fan and Evaporator Fan run. Accordingly, the normal operation is started. At this point, the operation light(GL) is on to indicate the refrigerator runs as the relay circuit 'a' is closed.

The relay circuit 'b' is opened and so the break light(RL) is off. Press the Stop button, and the magnetic switch(MC Electric Coil) is demagnetized. Then, the main contact is opened and so the Motor Compressor, Condenser Fan Motor and Evaporator Fan stop. Accordingly, the operation light(GL) is off and the relay circuit "b" is closed. Then, the break light(RL) is on to indicate that the operation stops.

As described above, the manual operation to start and stop the refrigerator is carried out by configuring the self-holding circuits using the relay circuit "a" of the magnetic switch (MC Electric Coil). The refrigerators run by pressing the Start button and stop by pressing the Stop button. This method can be applied for the tests, practices and circuit designing in the actual fields.









Experiment	4-2. Practice to co	onfiguration self-holding	circuit for	Required time			
name	priority STOP of PLO	8					
The Object of Experiment	 Understanding the working circuit, and make LD programming with XG 5000 tool as operate for refrgeration system Understand the working principle of run priority lock up circuit, and make LD programming with XG 5000 tool as sequence control circuit for refrigeration system. Using a standard refrigeration apparatus and refrigeration PLC training kit, practice to operate the apparatus with the PLC device by programming LD up-loaded and in-output circuit set up. 						
Experime	ent Equipment	Tool and Material	Spec of	Tools Q`nty			
 Standard Refri (KTE-1000BA) Refrigeration F (KTE-4000PLX) 	0	 Screw driver set Serial connector port Wire Stripper Hook Meter 	mm 1 1/grou p V 1 1/grou p				
< Stop priority	v lock up circuit >						

1. Sequence control circuit




L1,L2 : Line Voltage NFB : No Fuse Breaker R0 : Relay PB1, PB2 : Push button S/W Comp : Compressor Motor CFM : Condenser Fan Motor SV : Solenoid V/V

2. PLC transfer control circuit PLC



R_COMP : Relay for Compressor R_CFM : Relay for CFM R_SV : Relay for Solenoid V/V



L1,L2 : Line Voltage NFB : No Fuse Breaker Comp : Compressor Motor CFM : Condenser Fan Motor SV : Solenoid V/V R_COMP : Relay for Compressor R_CFM : Relay for CFM R_SV : Relay for Solenoid V/V

4. Variable memory distribution of PLC In-Output

Sec	Section		Туре	Device	Remark
	Input	PB1	BIT	P00000	
	Input	PB2	BIT	P00001	
Exterior variable		Comp	BIT	P00020	
	Output	CFM	BIT	P00021	
		SV	BIT	P00022	
interior	interior variable		BIT	M00000	




5. PLC Ladder


	P00000	P00001		MOOOD
1	PB1	PB2		RELA
	M00000			
Ī	RELAY0			
	M00000			P0002
5	RELAY0			COM
				P0002
				CFM
				P0002
				sv



6. Wiring and Motion








- 1) Connect the COM of the PLC INPUT.
- 2) Connect the push button to use. (PB1:P00 / PB2:P01)






- 3) Connect the COM of the PLC OUTPUT.
- 4) Connect the terminal "-" of the facility at the PLC OUTPUT
- 5) All the "+" terminals of the facility are +24 V



6) Connect the SIGNAL PORT of the PLC equipment and facility with a 36 pin cable.







Experiment	4-3. Practice to configuration of ter	mperature switch	-	Class tin	ne(hr)		
name	using sequence control						
The object of experiment	 To understand the principal of least temperature S/W, and adjust it. To configurate and operate circution To understand the feature after variation of low temperature point 	uit for low temper note and define of	rature co	ontrol .			
	Experiment equipments	Tool & material	Spec o	f tools	Q'nty		
. Standard (KTE-1000	refrigeration Experiment Equipment BA)	. Driver . Nipper . Wire Stripper . Hook meter	. #2 ² 175mm . 150m . 0.5~6 . 300A	m mm ²	1 1 1/Grou p		
	Control Circuit	t	1				
1. Basic co	PL MC PL MC Graph Graph Temp 9 Graph Temp 4 Service Valve Manual Expansion						



L1, L2 : Line voltage N.F.B : No fuse circuit COMP1 : compressor 1 MC-a : magnetic contact "a

CFM : Condenser fan motor SV1 : solenoid valve 1 EFM : Evaporator fan motor TC1 : Cascade1 output temp switch

No.	Temp	offset	In Temp	Out Temp	real temp	remarks
1	10	2				
2	8	2				
3	5	2				
4	0	3				
5	-2	3				

Temp setting \rightarrow Cut Out Point reaches \rightarrow Condensing Unit stop \rightarrow Temp Cut In Point \rightarrow Condensig Unit re-operate

On/Off operating in range of set temperature and diff(offset) range.


CUT-IN (stop \rightarrow run) point = temp setting + offset

CUT-OUT (stop \rightarrow run) point = temp setting - offset

ex) Temp set 2°C, offset 3°C,


CUT-IN point $2 + 3 = 5[^{\circ}C]$, CUT-OUT point $2 - 3 = -1[^{\circ}C]$.

* Temp control run/stop diagram





2. Temperature controller setting




- ① PV: Measurement display (red) Displays measured value. Displays configuration subject in configuration mode.
- ② SV: Configuration value display (green) Displays adjusting value. Displays configuration subject in


configuration mode.

- ③ SV2: SV2 on lamp
- ④ AT: auto-tuning on lamp
- (5) OUT: output on lamp
- 6 EV1,2: EVENT output display lamp
- ⑦ MD key: mode key
- Press button for 3sec
- ⑧ AT key: Auto-tuning run key
- ⑨ ▲ ♥ 《: adjustment key

* Method







* Caution: Offset [Configuration value ± offset/2] can be varied between operation range. ex) Configuration temp: 10, Offset: 4, In case of low temp control: starting at 10 + 2 = 12 [°C], stopping at 10 - 2 = 8 [°C]




Experiment name		Practice to configuration of temp	peratur	re swit	ch		me			
		using sequence control				6	8			
		Standard Refrigeration Equ	ipment							
· Check Po	int	(KTE-1000BA)								
	 Checking tools and materials. Setting the difference as the valves of LPS and explaining the operation principal of 									
 4. Understa ① Explai ② Explai ③ Explai ③ Explai 9 ress ④ Explai 5. noting at 	nding the ining the ure part ining the ure part ining the ining the nd defin	rcuit of operation with banana ja ne function of operating circuit. e progress when PB1 is pushed. e progress that the refrigerator i is goes down on running of comp- e progress that the refrigerator i is goes up on stop of compressor e progress that refrigerator starts ing distribution and variation of rcuit with electric wires and oper	s stop ressor s resta motor s wher high t	ed wł motor arted w n PB ₂ i emper	nen pressure 7. when pressu s pushed. ature points	e at lov re at lo	OW			
		Appraisal	Allot	Point	Rei	nark				
		Circuit configuration using banana jack	20							
Relationship	Work (Point	Circuit configuration using real wire	20							
between technical	70))	Configuration state	10							
description		Understand and description for circuit	20							
rating items and	Task (Point	Task attitude and safety	5							
task	10)	Application and standstill of tools	5							
	Time (Point 20)	• Demerit mark Point (in every () minute afte) er fin	ish	Work Task	Time	Total			




Experiment	4-4. Practice to configur	ration of temperature switc	h	Class time(hr)		
name	using PLC programming 8					
The object of experiment	 Temperature control, ar as sequence control circ 2 Control temperature control of refrigeration by recond 3 Using a standard refrigeration operate 	g principle of low pressure co ad make LD programming wit cuit for refrigeration system. ntrol , in order to grasp feat rding data of temp distribution eration apparatus and refrige the apparatus with the PLC of aded and in-output circuit set	h XG5000 tc ure on and devia ration PLC t levice by	tion.		
Ex	periment equipments	Tool & material	Spec of	tools Q'nty		
(KTE-1000)	ion PLC training kit	. Screw driver set . Serial connector port . Wire Stripper . Hook meter	. #2× 6 × 175mm . 150mm . 0.5~6m . 300A 60	1 1 m ² 1/Gro		
		Control Circuit				
L1 L2			M) SV	EFM		
L1,L2 PB COMP EFM	: Line Voltage N.F.H : Pushbutton R : Compressor Motor CFM : Evaporate Fan Motor	Breaker : Relay 7		Control S/W id Valve		



2. Conversion of sequence circuit for creating PLC ladder



3. Main circuit diagram of output part of facility






4. PLC ladder

	P00000	P00001	M000
1	PB1 M00000	PB2	RELA
	RELAY0		
	P00002		M000
5	TC_H M00001	M00002	RELA
	RELAY1		
	P00003		M000
10	TC_L	2100001	RELA
	M00002	M00001 —// RELAY1	
	M00000	M00001	P000
15	RELAY0	RELAY1	CON
			P000
			CFN P000
	M00000	M00002	SV P000
20	RELAY0	RELAY2	EFN




5. Wiring and motion






Sec	Section		Туре	Device	Remark
		PB1	BIT	P00000	
	Innut	PB2	BIT	P00001	
	Input	TC_H	BIT	P00002	
Exterior		TC_L	BIT	P00003	
variable	Output	COMP	BIT	P00020	
		CFM	BIT	P00021	
		SV	BIT	P00022	
		EFM	BIT	P00023	
		RELAY0	BIT	M00000	
interior	variable	RELAY1	BIT	M00001	
		RELAY2	BIT	M00002	



1) Connect the COM of the PLC INPUT.


2) Connect the push button to use. (PB1 : P00BPB 2 : P01)





- 3) Connect the high and low temperature of the temperature switch to the INPUT position on the PLC. (TC_H: P002TC_L:P)
- 4) Apply + 24V to the COM of the temperature switch.






- 5) Connect COM of PLC OUTPUT.
- 6) Connect the terminal " " of the facility at the PLC OUTPUT.
- 7) All the " + " terminals of the facility are + 24V.



8) Connect the SIGNAL PORT of the PLC equipment and facility with a 36 pin cable.







Experiment	4-5. Practice to configuration of lo	ow pressure switc	h(LPS)	Class t	ime(hr)
name	using sequence control				8
The object of experiment	 To understand the principal of and adjust it. To configurate and operate circ understand. To understand the feature after variation of low pressure. 	cuit for low press	ure conti	rol and	
	Experiment equipments	Tool & material	Spec of	f tools	Q'nty
. Standard (KTE-1000	refrigeration experiment equipment BA)	. Driver . Nipper . Wire Stripper . Hook meter	. #2× 6 175mm . 150mn . 0.5~6n . 300A 6	n nm²	1 1 1/Grou p
	Control Circo	uit			
1. Basic co	ntrol circuit	MC_a COLPS MC_a			
	PL MC	COMP CFM (SV J		
	Temp 0 Graph Temp 0 Fress 5 Temp 1 Fress 5 O00.0 Bar Fress 5 Temp 2 Fress 5 Temp 3 Graph Temp 2 Fress 5 Temp 3 Graph Temp 2 Fress 5 Temp 3 Graph Temp 1 Fress 1 O00.0 Bar Graph Compressor Compressor	SV SV Temp 7 Temp 7 Temp 7 Temp 7 Temp 7 Temp 7 Temp 7 Temp 7	Pressure Lipid		




	L1, L2 : Line voltage C				CFM : Condenser fan motor		
N.F.B : No-fuse breaker				SV1 : Solenoid valve 1			
		COMP	1 : 1 st stage o	comp	LPS : Low-pressur	e switch	
		PB∶p	oush button		MC : Magnetic con	tact	
	N.	Cut in D	חח	Cost and D	Deserves	Davida	
_	No.	Cut in P	D.P	Cut out P	Pressure gauge	Remarks	
	1	3	2	1			
	2	3	1	2			
	3	4	2	2			

The pressure control refrigeration system operation through pressure adjustment operation of LPS. Configure the circuit to be turned on/off according to the set pressure value, and operation the refrigeration system by performing C,H,L contact point control circuit configuration.

Operating refrigeration on/off cycle upon configurations below. CUT-IN (stop \rightarrow run) POINT = configuration pressure CUT-OUT (run \rightarrow stop) POINT = configuration pressure - offset ex) configuration pressure 5, offset 3 [bar] CUT-IN point 5 = 5[bar], CUT-OUT point 5 - 3 = 2[bar]

* LPS run/stop curve





2. Operate the cooling system through the pressure control circuit diagram

① When the power is connected via NFB, the Power Indicator (PL20) turns on. And PB1 switches or electronic contactor MC switches are all "b" contacts, so the other loads device is not energized.

② Press the PB1 switch, which is an "ON " switch, and the electronic contactor MC coil is created by creating an electric field by closing the MC switch contacts and keeping the MC_contact on the PC1 switch.

③ At the same time, the circuit will close the MC switch contact above the control unit Low Pressure Isolation Switch (LPS). If the LPS switch terminal is live and the pressure on the compressor suction side is lower than the ' cut-in ' pressure on the 'C' terminal and the pressure on the 'H' terminal is lower than the 'LPS' terminal.

④ If the pressure on the low pressure side is higher than the cut-in pressure and electricity flows to the 'H' terminal, the compressor and condenser compressor's compressor unit are not kept closed and the compressor valve is kept closed.

(5) If the compressor and the condenser are operated with the electronic valves closed, the refrigerant on the low pressure side continues to flow to the high pressure side, and the pressure on the high pressure side gradually rises, and the pressure on the low pressure side falls.

(6) If the pressure on the low pressure side falls below the cut-out pressure and the electricity flows to the 'L' terminal, the compressor and condenser are disconnected from the electrical valve and the electric valve opens.

⑦ If the electronic valve opens and the refrigerant flows to the low pressure side, the pressure on the low pressure side rises. When the pressure rises and reaches the single-entry contact, the LPS switch terminal is once again connected to the 'H' terminal, which closes the electronic valve, stopping refrigerant flow, and operating the compressor. Therefore, the cooling system by this control circuit repeatedly drops the switch on the LPS at the "H" terminal "L" terminal with the same low pressure change at the compressor inlet.

1 This control circuit is designed to reduce the periodic time of pressure load fluctuations on the low pressure side of the system, but not used in the case of an actual cooling system.

(9) If the PB2 switch is pressed, the magnetic flow of the MC coil is cut off, and the electricity supply of the refrigeration system is stopped.



3. LPS setting * Dual Pressure Switch (DPS) LPS low pressure control screw LPS offset control screw HPS high pressure control screww Reset Button Low Pressure Setpoint High Pressure Set point LPS Offset Set LPS "H" connect point HPS "H" connect point LPS "L" connect point HPS "C" connect point HPS "L" connect point LPS "C" connect point

DPS is a multi purpose switch which contains both low-high pressure swtiches. DPS consist of lever, contact adjust screw and run/stop compressor upon refrigerant pressure.


1) Structure

Referring the figure above, LPS is located below cover of DPS and Hand Pressure Switch (HPS) is located next to itself. There are 3 contact each which is 'C' below the LPS, 'A' above, 'H', and 'L'(B contact) on the upper side.

LPS contains pressure up/down adjust screw and HPS has manual return structure which lack of down pressure switch.

High/low pressure switch protects the equipment by opening/closing L,H contact upon high/low pressure configuration during equipment operation.





Right gradation: Low pressure (RANGE)

Left gradation: offset(DIFF)

- ① Adjust low pressure by turning the screw clockwise/anti-clockwise with screw driver(+)
- 2 Also adjust offset by turning the screw clockwise/anti-clockwise with screw driver(+)
- ③ Apply (+) power on com port and connect to certain port upon configuration (L or H) then connect other side of the cable to Comp (red port) next to DC power input.
- ④ LPS-L Line OUT (connect to COM -> L line port when pressure drops below configuration pressure)
- (5) LPS-H Line OUT (connect to COM -> H line port when pressure reaches up to configuration pressure)



2) H.P.S. method HPS high pressure control screww Reset Button High Pressure Set point HPS "H" connect point HPS "C" connect point HPS "L" connect point

- ① Adjust high pressure by turning the screw clockwise/anti-clockwise with screw driver(+)
- 2 HPS-L Line OUT (connect to COM -> L line port when pressure drops below configuration pressure)
- ③ HPS-H Line OUT (connect to COM -> H line port when pressure reaches up to configuration pressure, manual return by reset)




Experiment	4-5.	Practice to configuration of low	pressu	re swi	tch(LPS)	Time	
name		using sequence control					8	
		Standard Refrigeration Experimer (KTE-1000BA)	nt Equip	oment				
 Setting ting Configuration Configuration Configuration Understation Explained Explained	tools a he differ nding cir nding the ining the ure part ining the ure part ining the nd defin	nd materials. rence as the valves of LPS and recuit of operation with banana ja he function of operating circuit. e progress when PB1 is pushed. e progress that the refrigerator i goes down on running of comp e progress that the refrigerator i goes up on stop of compressor e progress that refrigerator start ing distribution and variation of recuit with electric wires and oper	cks us s stope ressor s resta motor s wher high t	ing to ed wh motor arted w n PB ₂ i emper	ols and nen pres r. vhen pr s pushe ature p	mate ssure ressur ed. oints	erial. at low re at low	f
		Appraisal	Allot	Point		Ren	nark	
Deletter	Work	Circuit configuration using banana jack Circuit configuration using real wire	20					
Relationship between	(Point		20					
technical description rating	70))	Configuration state Understand and description for circuit	10 20					
items and	Task	Task attitude and safety	5					
task	(Point 10)	Application and standstill of tools	5					
	Time (Point 20)	· Demerit mark Point (in every () minute aft) er fini	sh	Work '	Task	Time Tota	al



Experiment	4-6. Practice to	configuration of low pr	essure switch	Required time
name	(LPS)	using PLC programmi	ng	8
The Object of Experiment	 pressure S/W (LPS) as sequence contr 2 Control low pressure of refrigeration by 3 Using a standard kit, practice to op 	orking principle of low pres S), and make LD programm rol circuit for refrigeration ure at low pressure section recording data of temp di refrigeration apparatus and erate the apparatus with the up-loaded and in-output ci	ning with XG5000 system. , in order to gras stribution and de l refrigeration PL ne PLC device by	tool sp feature eviation.
Experime	ent Equipment	Tool and Material	Spec of Too	ls Q`nty
 Standard refrige equipment (KT) Refrigeration P (KTE-4000PLXC) 	PLC training kit	 Screw driver set Serial connector port Wire Stripper Hook Meter 	 #2×6×175mm RS-232C 0.5~6mm2 300A 6 00V 	1 1/Group 1 1/Group
1. Sequence c		TIOOK Meter	- 300A 0 00V	17010up
	PB1 0 0 PB1 0 0 PB2 0 PB2	Ro C H C C C C C C C C C C C C C C C C C	L1,L2 : Line Vol NFB : No Fuse F R0 : Relay PB1, PB2 : Push Comp : Compres CFM : Condense EFM : Evaportor SV : Solenoid V, PL : Power Lamp LPS : Low Press	Breaker button S/W ssor Motor r Fan Motor Fan Motor /V
	PB1 O $R0$ $LPS-H$ O $R1$ C $R2$ $R2$			ıxiliary relay npressor relay
PL Ro	Ri Ri	R- COMP CFM SV	R_SV : Sc	ondenser relay olenoid valve elay



3. Main circuit of device output




4. Variable memory distribution of PLC In-Output


Sec	Section		Туре	Device	Remark
	Input	PB1	BIT	P00000	
		PB2	BIT	P00001	
		LPS_H	BIT	P00002	
Exterior variable		LPS_L	BIT	P00003	
variable		СОМР	BIT	P00020	
	Output	CFM	BIT	P00021	
		SV	BIT	P00022	
		RELAY0	BIT	M00000	
Interior	variable	RELAY1	BIT	M00001	
		RELAY2	BIT	M00002	



5. PLC In-Output circuit









na	riment	4-6. Practice to configuration of	low pre	essure swit	ch Requ	ired time(l
	ame	(LPS) using PLC prog	rammir	ng		8
				Air-conditioning & Refrigers	tion PLC: Training Kit source	
	Star	ndard refrigeration apparatus (KTE-1000BA)	Refr	igeration PL (KTE-4000	-	kit
• Rec	quirement					
4. S€ 5. Ex ①	et deviatio xplain wor) Explain t) Explain t	uit with banana plug using a training kit n as LPS setting value, explain the worki k and function of circuit. the up-loading process of programming l the process when PB1 is pushed. the process when PB2 is pushed.	ing princ	ciple of LPS of	С.	
3 4 5 6. Re) Explain t down on) Explain t goes up ecord and	the process when the is pushed. the process that Comp stops with automative working compressor motor. the process that Comp works again with on stopping compressor motor. maintain the data of pressure distribution o circuit, connect to apparatus and operative	automati on and d	ic when low	pressure	-
3 4 5 6. Re) Explain t down on) Explain t goes up ecord and	the process that Comp stops with automative working compressor motor. The process that Comp works again with on stopping compressor motor. maintain the data of pressure distribution	automati on and d	ic when low eviation table	pressure	section
3 4 5 6. Re 7. Af) Explain t down on) Explain t goes up ecord and	the process that Comp stops with automa working compressor motor. The process that Comp works again with on stopping compressor motor. maintain the data of pressure distribution o circuit, connect to apparatus and opera	automati on and d ate it.	ic when low eviation table	pressure e.	section
3 4 5 6. Re 7. Af) Explain t down on) Explain t goes up ecord and ter set up	the process that Comp stops with automatic working compressor motor. The process that Comp works again with on stopping compressor motor. The data of pressure distribution circuit, connect to apparatus and operative distribution of the data of pressure distribution of the data of the data of pressure distribution of the data of the d	automati on and d ate it. Marks	ic when low eviation table	pressure e.	section
3 4 5 6. Re 7. Af) Explain t down on) Explain t goes up ecord and	the process that Comp stops with automatic working compressor motor. The process that Comp works again with on stopping compressor motor. The data of pressure distribution of circuit, connect to apparatus and operation of the programming work for control Lather Memory distribution of in, output Connection status of in,output main	automati on and d ate it. Marks 20 10	ic when low eviation table	pressure e.	section
3 4 5 6. Re 7. Af) Explain to down on) Explain to goes up ecord and ter set up	the process that Comp stops with automative working compressor motor. The process that Comp works again with on stopping compressor motor. maintain the data of pressure distribution or circuit, connect to apparatus and operative Criteria Programming work for control Lather Memory distribution of in, output Connection status of in,output main device	automati on and d ate it.	ic when low eviation table	pressure e.	section
3 4 5 6. Re 7. Af	Work (70)	the process that Comp stops with automative working compressor motor. the process that Comp works again with on stopping compressor motor. maintain the data of pressure distribution of circuit, connect to apparatus and operative and operative and operative apparatus appara	automati on and d ate it. 20 10 20 20 20	ic when low eviation table	pressure e.	section
3 4 5 6. Re) Explain to down on) Explain to goes up ecord and ter set up	the process that Comp stops with automative working compressor motor. The process that Comp works again with on stopping compressor motor. maintain the data of pressure distribution or circuit, connect to apparatus and operative Criteria Programming work for control Lather Memory distribution of in, output Connection status of in,output main device	automati on and d ate it.	ic when low eviation table	pressure e.	section



Experiment	4-7. Practice to configuration of h	nigh pressure swit	ch	Class t	ime(hr)
name	using sequence control			8	
The object of experiment	 To understand the principal of and adjust it. To configurate and operate circunderstand. To understand the feature after inderstand the feature after 	cuit for high pres	sure con distribut	trol and	
	variation of high pressure to c Experiment equipments	Tool & material	of conder Spec of		Q'nty
. Standard (KTE-1000)	refrigeration experiment equipment BA)	. Driver . Nipper . Wire Stripper . Hook meter	. #2× 6 175mm . 150mn . 0.5~6m . 300A 6	n nm²	1 1 1/Grou p
	Control Circ	uit			
1. Basic co	ntrol circuit				
	PL MC Temp Press Graph Temp 9 Temp 9	CFM COMP (KTE-1000BA Standard Refrigeration Trainer	SV I		
	Press 5 remp 3 Strice Valve 000.0 Bar Tomp 1 Press 1 Condenser Temp 1 Press 1 Press 2 Compressor	SV SV Temp 7 Temp 7 Temp 7 Low Low	rempe 8 Pressure Liquid + Yupor w Pressure Vapor alt Pressure Vapor alt Pressure Vapor		




	L1, L2	2 : Line voltag	CFM : Condenser fan motor			
	N.F.B	: No-fuse bre	SV1 : Solenoid valve 1			
	COMP	1:1 st stage o	LPS : Low-pressur	e switch		
PB : push button				MC : Magnetic contact		
No.	Cut in P	D.P	Cut out P	Pressure gauge	Remarks	
1	12	3	9			
2	12	2	10			
3	11	2	9			

The pressure control refrigeration system operation through pressure adjustment operation of HPS. Configure the circuit to be turned on/off according to the set pressure value, and operation the refrigeration system by performing C,H,L contact point control circuit configuration.

According to operate refrigeration on/off cycle upon configurations below CUT-IN (stop \rightarrow run) POINT = configuration pressure CUT-OUT (run \rightarrow stop) POINT = configuration pressure - offset ex) configuration pressure 12, offset 3 [bar] CUT-IN point 12 = 12[bar], CUT-OUT point 12 - 3 = 9[bar]

* HPS run/stop curve





2. Operate the cooling system through the high pressure control circuit diagram

① When the power is connected via NFB, the Power Indicator (PL20) turns on. And PB1 switches or electronic contactor MC switches are all "b" contacts, so the other loads device is not energized.

② Press the PB1 switch, which is an "ON " switch, and the electronic contactor MC coil is created by creating an electric field by closing the MC switch contacts and keeping the MC_contact on the PC1 switch.

③ At the same time, the circuit will close the MC switch contact above the control unit High Pressure Isolation Switch (HPS). The compressor and the SV connected to the MA-a contact output terminal are activated and the electricity flows to the hogh-pressore diferential pressure switch terminal. If the pressure on the outlet side of the condenser is higher than the pressure set by the differential pressure switch, electricity flows from the 'c' terminal to the 'H' terminal. If the pressure is lower than the LPS pressure, It flows toward the 'L' terminal.

④ If the pressure on the high pressure side is higher than the cut-in pressure and electricity flows to the 'H' terminal, Condenser fan is supplied to the motor to operate the condenser and start the refrigeration system operating. (Present, run as compressor, solenoid valve, condenser fan motor)


(5) During the operation of condenser, the refrigerant passes through the condenser inner coil and exchanges the heat with the wind supplied from the fan. Therefore, the refrigerant pressure in the high-pressure side is gradually lowered.

(6) When the pressure on the high pressure side becomes lower than the cut-out pressure and the electricity is changed from the 'c' terminal of the differential pressure switch to the 'L' terminal, the power supply to the condenser fan motor is cut off and the condenser is stopped.

⑦ The refrigerant circulates in the condenser without heat exchange, and the high pressure side pressure rises. When the pressure reaches the cut-in point, the differential pressure switch terminal is connected again to the 'H' terminal. Therefore, the condenser is restarted and the high-pressure side pressure is lowered. According to the high pressure change of the condenser outlet, it is a system in which the terminal of the differential pressure switch is repeatedly operated.

(1) If PB2 is pressed, the flow of electricity to the MC coil is cut off, self-holding circuit is cut off, and the refrigeration system is stopped.





The high-pressure switch consists of a section for setting the set value at which the condenser starts to operate and a deviation according to the operating range. The connecting hose connects with the high pressure part of the system (Outlet of condenser).

① Adjust high pressure setting value by turning the screw clockwise/anti-clockwise with screw driver(+).

② Adjust offset setting value by turning the screw clockwise/anti-clockwise with screw driver(+).

③ HPS-L Line OUT (connect to COM -> L line port when pressure drops below configuration pressure).

④ HPS-H Line OUT (connect to COM -> H line port when pressure reaches up to configuration pressure, manual return by reset).



Experiment	ritch	Ti	me						
name		using sequence control					8		
		Standard Refrigeration Experimen (KTE-1000BA)	nt Equip	oment					
· Check Po	int	(K1E-1000DA)							
2. Setting t		nd materials. rence as the valves of HPS and	explaiı	ning th	ne operatio	n princ	ipal		
 4. Understa ① Explain ② Explain ③ Explain ③ Explain ④ Explain 5. noting an 	nding the ining the ure part ining the ure part ining the nd defin	rcuit of operation with banana jan the function of operating circuit. The progress when PB1 is pushed. The progress that the refrigerator is a goes down on running of compar- te progress that the refrigerator is a goes up on stop of compressor the progress that refrigerator starts ing distribution and variation of rouit with electric wires and oper	s stop ressor s resta motor s wher high t ating	ed wł motor arted w n PB ₂ i emper- using f	nen pressu 7. vhen press s pushed. ature point tools and r	re at hig ure at h s naterials	nigh		
		Appraisal	Allot	Point	Re	emark			
		Circuit configuration using banana jack	20						
Relationship	Work	Circuit configuration using real wire	20						
between technical	(Point 70))	Configuration state	10						
description rating		Understand and description for circuit	20						
items and taskTaskTask attitude and safety5task(Point									
lask	(Point 10)	Application and standstill of tools	5						
Time (Point 20)· Demerit mark Point ()WorkTaskTime Time Time 0WorkTaskTimeTask									



Experiment	4-8. Practice to configuration of H	IPS on pressure s	switch	Class t	ime(hr)			
name	using sequence control							
The object of experiment	understand							
	Experiment equipments	Tool & material	Spec of	f tools	Q'nty			
. Standard (KTE-1000)	refrigeration experiment equipment BA)	. Driver . Nipper . Wire Stripper . Hook meter	. #2× 6 × 175mm . 150mm . 0.5~6mm ² . 300A 600V		1 1 1/Grou p			
	Control Circ	uit						
1. Basic co	ntrol circuit	MC_a HPS HC_a COMP CFM	a O Ob					
	Graph Temp 9 Press 5 Temp 4 Service Valve OKONO Bar	Standard Refrigeration Trainer	remp 8 c c resume Lipid + Fauer or Pressare Vapa et Pressare Vapa et Pressare Vapa					




	L1, L2	2 : Line volta	ge	CFM : Condenser fan motor			
	N.F.B	: No-fuse bre	SV1 : Solenoid valve 1				
COMP : Compressor			LPS : Low-pressur	e switch			
	TS : Togle switch			MC : Magnetic contact			
No.	Cut in P	D.P	Cut out P	Pressure gauge	Remarks		
1	6						
2	10						
3	14						

The HPS pressure adjustment operation can be used to forcibly stop the refrigeration system in case of abnormally high pressure.

After the equipment is configurated the wire according to the control circuit to start normal operation when the toggle switch is turned to contact 'b', the solenoid valve is closed and the high pressure is forcibly raised to enable the operation of the HPS


* Caution : Set the high pressure high and ensure that the low pressure drip to 0 bar during the experiment does not last long. (Open the SV within a reasonable time. Within 10 seconds)

1. Operation process of the high-pressure switch



Operation process of the high-pressure switch





① Adjust high pressure by turning the screw clockwise/anti-clockwise with screw driver(+).

② HPS-L Line OUT (connect to COM -> L line port when pressure drops below configuration pressure)

③ HPS-H Line OUT (connect to COM -> H line port when pressure reaches up to configuration pressure, manual return by reset)



Experiment									
name		using sequence control				8	3		
		Standard Refrigeration Experimen (KTE-1000BA)	nt Equip	oment					
· Check Po	int	(K1E-1000DA)							
		nd materials. rence as the valves of HPS and	explaiı	ning th	ne operation	princi	ipal		
 4. Understa ① Explain ② Explain ③ Explain ③ Explain ④ Explain 5. noting an an	nding the ining the ure part ining the ure part ining the nd defin	rcuit of operation with banana ja ne function of operating circuit. e progress when PB1 is pushed. e progress that the refrigerator i is goes down on running of comp e progress that the refrigerator i is goes up on stop of compressor e progress that refrigerator start ing distribution and variation of rcuit with electric wires and oper	s stop ressor s resta motor s wher high t	ed wł motor arted w n PB ₂ i emper	nen pressure r. when pressur s pushed. ature points	at hig re at h	iigh		
		Appraisal	Allot	Point	Ren	nark			
		Circuit configuration using banana jack	20						
Relationship	Work	Circuit configuration using real wire	20		1				
between technical	(Point 70))	Configuration state	10						
description rating	, ())	Understand and description for circuit	20						
items and task	Task (Point	Task attitude and safety	5						
lask	(Point 10)	Application and standstill of tools	5						
Time (Point 20)· Demerit mark Point ()WorkTaskTimeWork000000Work000000Work000000									




		C.	1	C 1	
Experiment	4-9. Practice to	_		01000 01	me(hr)
name	temperature (Tempe		-	re (LPS)	3
	control with a stand				
The object of experiment	(2) To make wiring a(3) To note and und	re S/W. as the circuit lerstand variati		e and pressure v	
	Experiment equipments		Tool & material	Spec of tools	Q'nty
. Standard (KTE-1000E	refrigeration experime 3A)	ent equipment	. Driver . Nipper . Wire Stripper . Hook meter	. #2× 6 × 175mm . 150mm . 0.5~6mm ² . 300A 600V	1 1 1/Grou p
		Control Circ	ıit		
1. Advan	L1(+)L2(-) N.F.B	PB2	Ry-a Ry-b Ry-a	V EFM	
	2 : Line Voltage : No fuse circuit ker	CFM : Condens Motor SV : Solenoid V	coil	:Magnet contacto -a:MC "a" contac	

- PB : Push buttonCOMP : Compressor motorPL : Power Lamp

	Evaporation		Evaporation		Operating(in)	, Stop(out) T.P
Test Steps	Temperature Setting(℃)	Deviation	Pressure Control (in P)	D.P	Temperature (Temp)	Pressure(P)
1	0	3				
2	-1	3				
3	-2	3				
4	-3	2				
5	-4	2				
6	-5	2				

1. 1. Serial and Parallel Circuit Configuration




EXE NO . 2


The switches and controllers are generally connected in series. They control and manage more than one loads each. The electric circuit that we can understand the most easily and simply is the serial circuit. In the serial circuit, the current shall pass through one circuit. The serial circuit is connected to most control circuits in the heating and air conditioning and refrigeration devices.

The control circuit means the electric circuit controlling several important loads in the device. If all control components are connected on the circuit in series, opening the components or switches make the circuit open and loads intercepted as shown in EXE No. 2.





The serial circuit is used as the electric circuit in the heating, air conditioning and refrigeration devices for controlling the temperature and devices. EXE NO, 3 shows the circuit on the controller. The controller is connected to the devices that are controlled by the electric motor in series. The serial circuit includes the safety devices required to keep the safe operation of devices. EXE NO, 4 shows how the safety devices are connected to the serial circuit in order to stop the compressor if any unstable operations are occurred. In this case, if the safety device is opened, the relevant circuit is also opened and so the compressor stops working.




The currents in the serial circuit flow in the same way on the entire circuit because there is only one channel that the currents can follow.


 $I = I_1 = I_2 = I_3 = I_4 \dots$

The parallel circuit has more than one channels for the currents in the heating and cooling system. The currents in the parallel circuit can flow along more than two channels at the same time. The parallel circuit is used in the heating and cooling system control industry because most loads work with each line voltage. The line voltage is supplied from the main power unit to a specific unit, which is generally 100V or 220V. The parallel circuit is aligned to enable the line voltage to reach to all loads connected in parallel as shown in EXE NO, 5. Each load in the circuit is supplied with the line voltage of 220V.



The parallel circuit is used to supply the accurate line voltage to each circuit in the controller, which is called "Power Circuit". EXE NO, 6 presents the controller with several circuits in the parallel circuit with the line voltage. Many other circuits with the currents are configured in the parallel structure as shown in the figure. Each circuit connected from the line 1 to the line 2 are connected to other circuits in parallel and receives the voltage. The parallel circuits are used in all power circuits supplying the loads of air conditioning and refrigeration devices. The loads in a device need to be connected to the power supply unit in the separate types or in parallel to supply the sufficient line voltage to loads. It is very rare that the field engineers calculate the currents or voltages in the parallel circuits, but the designers decide them in most cases. However, the field engineers are very familiar with the principles or concepts of basic parallel circuits. The currents in the parallel circuits have the fixed values for each circuit sector and some variables are generated depending on the resistance in each sector in the circuit.





All currents in the parallel circuit match up to the total currents on each sector. The currents on each sector in the circuit are calculated when the resistance and voltage are given. The equation for all currents in the parallel circuit is:

 $\mathbf{I} = \mathbf{I}_1 + \mathbf{I}_2 + \mathbf{I}_3 + \dots$

For the parallel circuit, the more the resistance is applied to the circuit, the smaller the entire resistance becomes. All resistances in the parallel circuit can't be calculated by adding all resistances. The total resistance can be obtained according to the formula below.

The reciprocal proportion of total resistance matches up to the value adding the reciprocal proportion of each resistance. The formula belows describes it.

The split voltage in the parallel circuit is the line voltage on the loads. Each load in the parallel circuit is the entire voltage on the loads. For example, if 220 V is applied to one load, it means that the load has the entire voltage 200V.

$$V = V_1 = V_2 = V_3 = V_4 = \dots$$

The serial-parallel circuit combines the serial and parallel circuits. It is found in the entire wiring design for the air conditioning and refrigeration devices. This type of electric circuit mixes the serial and parallel circuit as shown in EXE NO. 7. The serial-parallel circuit can be more easily understood when it has several components. If not, it is very difficult to understand it. The serial-parallel circuit is used to connect the circuit supplying the power to loads to the control circuit. Most serial-parallel circuit applications aim to supply the accurate voltage to the contact lines with the switches to enable all loads to control the devices in series. Each electricity in the serial-parallel circuit shall be carefully measured because each proportion of circuit can be explicitly defined as serial or parallel circuit. Once the circuit line is defined, the electricity shall be calculated later.



	4-9.	Practice to confi	igurate	direct	circui	it for	low	Tin	ne
Experiment name	tempe	rature (Temperature	e S/W)	and low	v pres	ssure (L	.PS))
	contro	ol with a standard re	efrigerati	ion syst	em			8	5
		Standard Refrigerat	ion Experin	nent Equip	oment				
 Standard Refrigeration Experiment Equipment (KTE-1000BA) Check Point Configurating circuit of operation with banana jacks using tools and material. Understanding the feature of direct circuit using automatic control switch(temperature, pressure) and explaining it. Understanding the function of operating circuit. Explaining the progress when PB1 is pushed. Explaining the progress that the refrigerator is stopped when the temperature switch or pressure switch is opened on running. Explaining the progress that the refrigerator is restarted when the temperature switch or pressure switch is closed on no running. Explain the progress that refrigerator is operated when PB2 is pushed. Noting and defining distribution and variation of pressure points Configurating circuit with electric wires and operating using tools and materials. 									
		Appraisal		Allot	Point		Rema	ark	
		Circuit configuration us jack	ing banana	20					
Relationship	Work	Circuit configuration usin	ng real wire	e 20					
between technical	(Point 70))	Configuration s	state	10					
description rating		Understand and descr circuit	ription for	20					
items and task	Task (Deint	Task attitude and	l safety	5					
	(Point 10)	Application and stands	still of tool	s 5					
	Time (Point 20)	• Demerit ma in every ()	rk Point minute a	```	sh	Work T	ask 7	Гime	Total

Korea Technoloby Engineering Co.,Ltd.

Experiment	4-10. Practice to configurate c	ontrol circuit fo	or pump	Class time(h	ır)
name	down with a standard refrigeration	on system		8	
The object of experiment	 To understand and applicate the in refrigeration system. To configurate pump down circuit. To wire pump down circuit. To set the value of temperature down operation. To note and understand variati system is operated as pump down down down down down down down down	cuit. e S/W and pressu on of temperatur	ure S/W f	or pump	1
	Experiment equipments	Tool & material	Spec of	tools Q'n	ıty
. Standard (KTE-1000B	refrigeration experiment equipment A)	. Driver . Nipper . Wire Stripper . Hook meter	. #2× 6 175mm . 150mm . 0.5~6m . 300A 6	1 n 1 nm ² 1/Gr	rou
	Control Circ	uit	L		
	ced control circuit to temperature s	Ry-a ●		FM	
	L1, L2 : Line Voltage N.F.B : No fuse circuit breaker PB : Push button MC-a : MC "a" contact RY : Relay coil Ry_a : Relay "a"contact Ry_b : Relay "b"contact YL : Yellow Lamp	COMP : Comp CFM : Conder SV : Solenc MC : Magnet LPS : Low F TC : Temper PL : Power GL : Green	nser Fan Mo Did V/V contacto Pressure S cature con Lamp	tor r coil /W	



2. Operating cooling system through temperature control circuit diagram

① Check if the power lamp turns on when N.F.B power is applied. Press PB1 to confirm that the MC is powered.

2) Press PB1 to explain the operation process. Mc-a is actuated, and the TC (Thermostat) is powered and Comp, CFM, SV (Open) and EFM are operational according to the set temperature values.

③ If PB1 is pressed, L contacts are operated in the TC (Temperature Controler), and EFM is operated.


④ If PB1 is detached, the H contact of the TC is powered. Therefore, Comp, CFM connected to H contact is operational and SV opens.

⑤ TC (thermostat) refers to the control of evaporation temperature. The temperature setting value is set to the ambient air temperature (ambient air temperature or exit) or below. Construct a circuit to enable the H contact to operate, since the current evaporation temperature is higher than the established evaporation temperature. When the H contact is active, the connected Comp and CFM are operated and the SV (Solenoid Valve) open to reduce the evaporation temperature. When the evaporation temprature value is lower than the TC set value through H contactor control, the L contacts energised.

(6) When power is applied to the L contact, Comp and CFM connected to the H contact are turned off, while the SV closes, and EFM operates to give evaporation load.

⑦ Connect the circuit as shown in the control diagram, and check if the above operating cycle operates repeatedly.





Test Steps	Evaporation Temperature Setting(°C)	Deviation	Evaporation Pressure Control(in P)	D.P	Remarks
1	0°C	2 or 1			
2	-1°C	2 or 1			
3	-2°C	2 or 1			
4	-3°C	2 or 1			
5	-4°C	2 or 1			
6	-5°C	2 or 1			
7	-6°C	2 or 1			

4. Practice of operating the pump down control circuit with contact control (C, H, L)

① When the power is turned on the breaker N.F.B, the power indicator(PL) is turned on. The 'a' contact of the PB1 switch or the Magnetic Contactor, Ry, MC switch does not supply electricity to the other load device because only the YL connected to the Ry switch 'b' contact is

turned on.



② When the 'ON' switch PB1 is pressed, a magnetic field is formed through the relay roil. The Ry switch contact. Ry_a contact, is then closed and the PB1 switch is turned off conversely. Ry_b contact is opened and YL is turned off.

3) At the same time, electricity is supplied to the low-pressure switch and the temperature switch terminal, which are control devices, in the circuit diagram. In the case, if the low-pressure line pressure on the suction side of the compressor is higher than the pressure set in LPS, electricity flows from the 'c' terminal to the 'H'terminal. On the other hand, if less than the LPS set pressure, electricity flows from the 'c' terminal to the 'L'terminal. In the case of the temperature switch, electricity flows from the 'c'terminal to the 'H'terminal of the 'L'terminal according to the set temperature of the evaporator outlet.

④ When the evaporator outlet temperature is higher than the set temperature and the electricity flows to the 'H'terminal, the solenoid valve is opened and at the same time the low pressure side is higher than the set pressure. Electricity is supplied and refrigeration system operation is activated.

(5) When the evaporator outlet temperature drops below the se temperature due to sufficient refrigeration system operation, the contact of the temperature switch is connected from the 'c'terminal to the 'L'terminal, and the solenoid valve is closed. When the compressor and the condenser operate with the solenoid valve closed, the refrigeration on the low pressure side flows continuously to the high pressure side, so that the pressure on the high pressure side gradually rises and the pressure on the low pressure side drops.

(6) When the pressure on the low pressure side becomes lower than the set pressure and electricity flows to the 'L'terminal, the electricity supply to the compressor and the condenser is cut off and the operation is stopped. When the solenoid valve is closed, the compressed refrigerant is collected in the liquid receiver. (Pump down)

⑦ When the evaporator outlet temperature rises and the solenoid valve is opened again and the refrigerant filled in the receiver flows to the low pressure side, the pressure on the low pressure side rises. When the pressure rises to reach the set value, the LPS switch terminal is connected again to the 'H'terminal to start the compressor and the condenser start the refrigeration system operation. Therefore, this control circuit uses a temperature switch and a pressure switch to automatically shut down the equipment when the evaporator temperature reaches a certain temperature and to pump down the circuit.

(8) When you press the switch 'PB2' which is 'off' switch, the flow of electricity to the Ry coil is cut off, self-holding is cut off and the refrigeration system is stopped because the electricity supply to the refrigeration system is cut off.




Experiment	4-10	. Practice to configuration of	pump	down	control	Tir	me		
name		circuit using sequence contro	ol			8	3		
		Standard Refrigeration Equ	ipment						
· Check Po	int	(KTE-1000BA)							
, Clieck PO	IIII								
 Configura Understa switch(te Understa Understa Explai Explai Explai Explai Explai Sexplai Noting a 	 Checking tools and materials. Configurating circuit of operation with banana jacks using tools and material. Understanding the feature of parallel circuit using automatic control switch(temperature, pressure) and explaining it. Understanding the function of operating circuit. Explaining the process when PB1 is pushed. Explain the process that temperature S/W is opened on running. Explain the process that refrigerator stops when pressure S/W is opened Explain the process that refrigerator stops when PB2 is pushed. Noting and defining distribution and variation of pressure points Configurating circuit with electric wires and operating using tools and materials. 								
		Appraisal	Allot	Point	Ren	nark			
		Circuit configuration using banana	20						
Relationship	Work	jack Circuit configuration using real wire	20						
between	(Point 70))	Configuration state	10						
technical description	,0))	Understand and description for							
rating		circuit	20						
items and task	Task (Point	Task attitude and safety	5						
tusk	10)	Application and standstill of tools	5						
Time (Point 20)• Demerit mark Point () in every () minute after finishWorkTaskTime Time Time Time Time Time Time Time Time Time Time Time Time 							Total		



Experiment	4-11. Practice to configuration of pump down control circuit using PLC programmingRequired time8					
name						
The Object of Experiment	 Use XG5000 tool to build ladders and run the PLC. Set a temp S/W and a pressure S/W for pump down operation, in order to grasp feature of refrigeration by recording data of temp 					
Experimen	nt Equipment	Tool and Material	Spec of 1	fools Q`nty		
 Standard Refri Equipment (KT) Refrigeration PL (KTE-4000PLXG) 	C training kit	 Screw driver set Serial connector port Wire Stripper Hook Meter 	 #2×6×175r. RS-232C 0.5~6mm2 300A 600V 	1/grou p		
 Sequence con NFB MC CFM CFM CFM PLC transfer 	PL Ro YL G	NF R ₀ PB CO CF EF FF CC CF EF SV CL CC CF CF CF CT CT CT CT CT CT CT CT CT CT	L ₂ : Line Volta B : No Fuse E : Relay n, PB ₂ : Push I mp : Compres M : Condense M : Evaportor : Solenoid V/ : Power Lam : Green Lam : Yellow Lam 2 : Temp con S : Low Press	Breaker button S/W ssor Motor r Fan Motor Fan Motor /V p p p trol S/W		
PL R0		R0 R0 LPS-H C-H R0 TC-H R_MC R_SV R_SV	: Low p High p : Temp High ten : 1	xiliary relay ressure switch pressure side(H) perature S/W nperature side(H) MC Relay magnetic valve Relay		






4. Variable memory distribution of PLC In-Output

Section		Variable	Туре	Device	Remark
		PB1	BIT	P00000	
		PB2	BIT	P00001	
Exterior	Input	LPS_H	BIT	P00002	
		TC_H	BIT	P00003	
variable	Output	СОМР	BIT	P00020	
		CFM	BIT	P00021	
		SV	BIT	P00022	
		YL	BIT	P00023	
interior variable		RELAY0	BIT	M00000	
		RELAY1	BIT	M00001	



5. PLC In-Output circuit






6. PLC Ladder programming

	P00000	P00001	M0000
1	PB1	PB2	RELAY
	M00000		
	RELAY0		
	M00000		P0002
5	RELAY0		YL
-	M00000	P00002	MOOOD
7	RELAY0	LPS_H	RELAY
		P00003	P0002
		тс_н	sv
	M00001		P0002
14	RELAY1		COMF
0.00			P0002
			CFM
			END







Experiment	4-12. Configura	tion hot gas defrost	ting circuit	Required time	
name	and operation			8	
The Object of Experiment	 ① To understand about effect and reason of frost on evaporator ② To understand and applicate principal of hot gas defrost when frost cause on evaporator ③ To configurate hot gas defrost circuit of refrigerator 				
Experimen	nt Equipment	Tool and Material	Spec of To	ools Q`nty	
 Standard Refrig Equipment (KTI 	geration Experimen [.] E-1000BA)	 Screw driver set Serial connector port Wire Stripper Hook Meter 	 #2×6×175n RS-232C 0.5~6mm2 300A 600V 	1/group 1	
1. Sequence con	trol circuit				
L1(+) L2(-) N.F.B MC1_a MC2_a MC2_a	THR October MC3_a MC3_a EFM	Ry RL T MC1		SV2 (WL) GL	
L1, L2 : Line F N.F.B : No fuse MC-a : MC "a" c COMP : Compress CFM : Condenser THR : Thermal F EFM : Evaporato	circuit breaker MC : contact SV : sor motor TC : Fan Motor GL : Relay T-a	24hrs Timer Coil Magnet Contactor Solenoid V/V Temperature control S/W Green Lamp : Timer "a" contact : Timer "b" contact		Lamp ay "a" contact ay "b" contact coil amp	



2. Related Theory ST. Expansion v/v V1 Fillter Drier Receiver Evaporator ST. Heat Condenser S.V1 V3 Exchanger Sight 1 Glass -S.V2 Compressor Accumulator

Output terminal symbols of refrigeration system

- COMP : Compressor Motor
- CFM : Condenser Fan Motor
- EFM : Evaporator Fan Motor
- S.V1 : Solenoid Valve 1 (Main V/V)
- S.V2 (HD) : Solenoid Valve 2 (Hot gas V/V)



Experiment	4-1	2. Configuration hot gas defro	sting	circui	t and	Ti	me
name	ope	ration					8
		Standard Refrigeration Equ	ipment				
 Check too Understand Understand Expland Expland Expland Expland Expland Configuration Configuration Configuration 	 (KTE-1000BA) Check Point 1. Check tools and materials. 2. Understand and explain purpose and effect of defrost. 3. Understand the function of operating circuit. Explain the progress when PB1 is pushed. Explain hot gas defrosting progress during operation. Explain the progress that hot gas defrost operation stops and system runs commonly. Explain the progress that refrigerator stops when pressure S/W is opened note and define distribution and variation of low pressure. Configurate circuit using banana jacks and operate using banana jacks with experiment equipments, tools and materials. Configurate circuit using real wires and operate using banana jacks with experiment equipments, tools and materials. 						
		Appraisal	Allot	Point	R	emark	
		Circuit configuration using banana jack	20				
Relationship	Work	Circuit configuration using real wire	20				
between	(Point 70))	Configuration state	10				
technical description rating		Understand and description for circuit	20				
items and	Task (Point	Task attitude and safety	5		4		
task	10)	Application and standstill of tools	5				
	Time (Point 20)	· Demerit mark Point (in every () minute aft) er fini	sh	Work Tas	k Time	Total



Experiment	4-13. Configu	aration electric heat	defrosting	Required time	
name	circuit and ope	ration		8	
The Object of Experiment	 ① To understand about effect and reason of frost on evaporator ② To understand and applicate principal of total enthalpy defrost when 				
Experime	nt Equipment	Tool and Material	Spec of To	ools Q`nty	
• Standard Refri Equipment (KTI	geration Experime E-1000BA)	ent · Screw driver set · Serial connector port · Wire Stripper · Hook Meter	 #2×6×175m RS-232C 0.5~6mm2 300A 600V 	1/group 1	
1. Sequence con	trol circuit				
	AC2_a of of MC3_a of	THR PB2 PB2 PB2 Ry_a PL Ry Ry_a MC1 (St		T_a JTC2 L MC3 (VL	
L1, L2 : Line Po N.F.B : No fuse MC-a : MC "a" co COMP : Compresso CFM : Condenser D THR : Thermal Ro HPS : High Press H.T : Heater	circuit breaker MC ontact SV or motor TC Fan Motor GL elay T-a	24hrs Timer Coil Magnet Contactor Solenoid V/V Temperature control S/W Green Lamp Timer "a" contact Timer "b" contact		Lamp y "a" contact y "b" contact coil np	



Experiment	4-1	13. Configuration electric heat defrosting circuit and Tim					me	
name	oper	ration					8	3
		Standard Refrigeration Equ	ipment					
 Understan ① Explain ② Explain ③ Explain ④ Explain 4. note and 5. Configuration 6. Configuration 	ols and r nd and ex nd the fr in the pr in total in the pr oly. in the pr define of ate circ s, tools ate circ	(KTE-1000BA) materials. xplain purpose and effect of defr unction of operating circuit. rogress when PB1 is pushed. enthalpy defrosting progress dur rogress that total enthalpy defro rogress that refrigerator stops w distribution and variation of low uit using banana jacks and operat and materials. cuit using real wires and operat and materials.	ing ope st oper hen pre pressu te usin	ation essure ure. ng bana	stops S/W is nna jac	opene ks wit	d h expe	riment
		Appraisal	Allot	Point		Ren	nark	
	Warl	Circuit configuration using banana jack	20					
Relationship between	Work (Point	Circuit configuration using real wire	20					
technical	70))	70))Configuration state10Understand and description for						
description rating		circuit	20					
items and	Task (Point	Task attitude and safety	5					
task	(Point 10)	Application and standstill of tools	5					
	Time (Point 20)	• Demerit mark Point (in every () minute aft) er fini	sh	Work	Task	Time	Total



Chapter 5. Notice and Guarantee

1. Mechanical trouble and measures

- 1-1. When the Power lamp does not connect
- (1) If the power lamp do not work when the N.F.B turn on. Please check inserts a power cord in the reverse side of N.F.B or installation in power input.
- 1-2. When trouble of the other parts
- (1) Contact us when Operation of other parts is strange or out of work. Then we will handle rapidly.

2. Caution Notice on operation

- 2-1. Power Supply
- (1) Main power of this equipment is use a single phase AC 220V.
- (2) After equipment action order turns on N.F.B and watches circuit diagram and finishes wiring by RCA cable in proposition that power cord was counted, DC toggle switch does on.
- (3) Use RCA cable and power supply at equipment operate secures because use DC 24V, but should observe to +, - mixing use of monad as operating power is DC.
- (4) Also, base and control panel of equipment is all aluminum quality of the material when interlink red + terminal, should take care not to reach in aluminum base.

2-2. Machine Equipment

- (1) When using a charging nipple installed at low pressure and high pressure side of, notice refrigerant not to leak.
- (2) Use after making sure how to use well exactly operating a manual expansion valve .
- (3) When going out of factory, super heating and sub cooling are set up $5\pm 2^{\circ}$, but as your continue using the setting value will be changed.
- (4) Notice fragile arcrylic duct of evaporator for visual inside. Be careful not to break it.
- (5) If you separate any component of product by yourself, the system gets damage and you never get A/S from us.
- 2-3. Data Acquisition device and Software
- (1) After set up circuit of electric panel on the main equipment, connect Data Acquisition device and computer. Check if the cable is connected correct, turn on the switch on panel.(* Please follow step by step as manual book.)



2-4. Else

- (1) After reading the manual book, operate the system.
- (2) If you have any question, call us.
- ◎ Warrantee and A/S application sheet

Product Warrantee Certification Fill out this sheet, and send by Fax or E-mail						
MODEL						
WARRENTEE 1 YEAR						
PURCHASING DATE (M/D/Y)						
	SCHOOL					
ORGANIZATION	DEPARTMENT					

Headquarters :679-7 2FI Sinhyun-Li, Opo-Eup, Gwangju-City, Gyonggi-Do, KOREA (zip : 464-895) Head Office : #133-1 Sinhyun-li, Opo-eup, Gwangju-City, Gyeonggi-Do KOREA (zip : 464-895) TEL: +81-31-749-5373 | FAX: +81-31-749-5376 | kteng@kteng.com | www.kteng.com









Renewable Energy / Refrigeration & Air-conditioning & Welding Automation controls(PLC) / Robot controls / Electric & Electronics(LED lighting) Firefighting & safety / Big data & ICT / Automobile & ship / Nano chemical





KTENG Co., Ltd. TEL: 82-31-749-5373 | FAX: 82-31-749-5376 overseas@kteng.com | http://www.kteng.com 11, Meorusut-gil, Opo-eup, Gwangju-si, Gyeonggi-do, 12771, South Korea